


Functions:


- (1) On/off Press "on/off" button to switch on.
 - A beep sound occurs indicating the unit is switched on.
 - LCD display shows all functions for a seconds and then turn to normal mode.
 - (i) pressure: in the unit of mb (mbar) (or inHg).
 - (ii) height: shows in the unit of m (meter) (or ft).
 - (iii) temperature: shows in the unit of °C (or °F).
 - (iv) direction: shows in whole circle bearing, e.g. 255° (or compass bearing e.g. S75W (=255°)).
 - (v) time: shows and starts time at 12 hour format. e.g. 12:00am (or 24 hour format).
 - (vi) calendar: shows in d/m with day (or m/d).
 - (vii) bar graph (viii) weather forecast: show in graphic icon.
- To operate under the scope of the above (i) to (viii), press "mode" to switch as following:
- (i) "BARO", "ALT", "TEMP" and "CAL".
 - (ii) "TEMP", "DIR", "TIME" and "CAL".
 - (iii) "BARO", "ALT", "TEMP", "TIME", "DIR", "TEMP" and "CAL".
- (2) Press and hold "on/off" for 3 seconds to switch off.




(A) ~ (G): "Function" Display

Measurement and Display function


- (A) Pressure
 - (1) Press "mode" to pressure mode. [BARO] appears, Bar graph for the pressure trend of previous 12 hours shows.
 - (2) Press "mode" again to exit and switch to the "ALT" mode.



- (2) BARO mode includes following functions:
 - (a) Real-time pressure reading in mb (hPa) or inHg.
 - (b) Pressure trend reading (past 12 hours readings) to switch between (a) and (b), press "+" and "-" together.
 - (3) Air pressure unit switchable
 - (i) Go to (2a).
 - (ii) Press together "set" and "+" to switch between mb (hPa) and inHg.
 - (4) Pressure Trend (past 12 hours reading)
 - (i) Go to (2b). Display will show one pressure reading for the previous past hour with "1hr" next to the reading.
 - (ii) Press "+", "or" "-" to check record of reading in other hours within the past 12 hours.




- (3) Altitude unit switchable
 - (i) Go to (2a).
 - (ii) Press together "set" and "+" to switch between m or ft.
- (4) Setting a reference altitude
 - (i) Press "mode" to TEMP mode. [TEMP] appears.
 - (ii) Press "mode" again to exit and switch to "DIR" (or "TIME") mode.




(B) Altitude


- (1) Press "mode" to altimeter mode. [ALT] appears. Bar graph for the altimeter trend of previous 12 hours shows.
- (2) ALT mode includes following functions:
 - (a) Real time altimeter reading in m or ft
 - (b) Max/min altimeter memory recalling
 - (c) Altimeter Trend (past 12 hours reading)
 - (d) High/low altimeter alarm
 - (e) Current ascent/descent rate in ft/hr or m/hr
 - (f) Ascent/descent differential altitude ▲, ▲H; ▼, ▼H
 - (g) Accumulative ascent/descent altitude Σ+, ▲ or Σ+, ▼





- (C) Temperature
 - (1) Press "mode" to TEMP mode. [TEMP] appears.
 - (2) TEMP mode includes following functions:
 - (a) Real-time temperature reading; and (b) Temperature trend
 - (An arrow shows on the display representing the temperature is)
 - (i) rising; or
 - (ii) steady; or
 - (iii) down going
 - (3) °C/F switchable
 - (i) Go to (2a)
 - (ii) Press together "set" and "+" to switch between °C and °F.
 - (4) Temperature max/min memory recalling
 - (i) Go to (2a)
 - (ii) Press "+", "or" "-" to show maximum temperature tested. [MAX] shows on the display.
 - (iii) Press "-", "or" "-" to show minimum temperature tested. [MIN] shows on the display.
 - (iv) Press and hold "set" to clear memory individually. Display returns to real time in 5 secs.




- (6) Altitude max/min memory recalling
 - (i) Go to (2b). display shows the maximum reading.
 - (ii) Press "+", "or" "-" to turn on the reference altitude setting and "On" display.
 - (iii) Press "set" to confirm, real time altitude flashing.
 - (iv) Press "+", "or" "-" once to increase one digit or press and hold "+" to for acceleration or increments.
 - (v) Press "-", "or" "-" once to decrease one digit or press and hold "-" for acceleration or increments.
 - (vi) Press "set" to confirm and real time altitude change to the preset value for altitude calculation.
- (7) Altitude Trend (past 12 hours reading)
 - (i) Go to (2c). Display will show one altimeter reading for the previous past hour with "1hr" next to the reading.
 - (ii) Press "+", "or" "-" to check record of reading in other hours within the past 12 hours.
- (8) High/low altimeter alarm
 - (i) Go to (2d), display shows flashes "AL".
 - (ii) Press and hold "+", "or" "-" to set and check high alarm, "AL" and, "HI" flashes, -700m or measurement again. Display reads real time reading immediately and update every second immediately.
 - (iii) Press and hold "-", "or" "-" to set and check low alarm, "AL" and, "LOW" flashes, -700m or previous reading shows on the display.
 - (iv) Press "set" to confirm and the display returns to (2a) press 100ht.
 - (v) Press and hold "set" to confirm and the display returns to (2a) When the reading reaches the alarm setting, alarm beep turns on for 15 times, "HI" or "LOW" flashing.



- (9) Current ascent/descent rate
 - (i) Go to (2e), display shows the current ascent rate. "▲" shows on the display.
 - (ii) Press "-", "or" "-" to show current descent rate.
 - (iii) Press "+", "or" "-" together
 - (iv) Press "set" to return to (2f).
- (10) Ascent/descent differential altitude
 - (i) Go to (2f), display shows the ascent differential altitude reading.
 - (ii) Press "+", "or" "-" to show ascent differential altitude reading.
 - (iii) Press "-", "or" "-" to show descent differential altitude reading.
 - (iv) Press "set" to return to (2g).
 - (v) Press "+", "or" "-" together to switch (2g) altitude reading.
 - (vi) Press "set" to return to (2g).




- (11) Accumulative ascent/descent altitude
 - (i) Go to (2g), display shows the accumulative ascent altitude reading.
 - (ii) Press "+", "or" "-" to show accumulative ascent altitude tested. "F" and "▲" shows on the display.
 - (iii) Press "-", "or" "-" to show maximum temperature tested. [MAX] shows on the display.
 - (iv) Press "+", "or" "-" to show minimum temperature tested. [MIN] shows on the display.
 - (v) Press and hold "set" to clear memory individually. Display returns to real time in 5 secs.



(D) Direction

To look for Compass information:

- (1) Press "mode" to DIR mode. DIR appears. Press again to exit and switch to "TIME" mode.
- (2) DIR mode includes following functions:
 - (a) Real time direction reading in whole circle bearing or compass bearing
 - (b) Calibration function
- (3) Type of bearing switchable
 - (i) Press "set" and "+" to switch between different types of bearing.
- (4) Calibration
 - (i) In "DIR" mode, Press and hold "set". "CAL" appears.
 - (ii) Turn the unit for 360 degree horizontally.
 - (iii) Press and hold "set" to confirm and exit to real-time compass.
- (5) Sleep mode
 - (i) When the unit is in the compass mode, it starts to measure and update the direction every second for 1 minute.
 - (ii) Afterward the display read "---".
 - (iii) In compass mode, press "set" to reactivate the unit to measure and update the direction every second for 1 minute; or
 - (iv) Press "mode" to exit and re-enter to the DIR mode again.




(E) Time

To look for TIME information:

- (1) Press "mode" to time mode. TIME shows on the display. Press "mode" again to exit and switch to "CAL" mode.
- (2) TIME mode includes following function:
 - (a) Real time clock
 - (b) Alarm time setting (▲ shows on the display)
 - (c) Timer (count up and count down); ▼ shows on the display

To switch between (a) to (c) one by one, in TIME mode press together "+" and "-" for each switching.
- (3) 12/24switchable
 - (i) Go to (2a).
 - (ii) Press together the "set" and "+" to switch between 12/24 time format.
- (4) Clock Set
 - (i) Go to (2a), press and hold "set". Hour digits flash.
 - (ii) Press "+" or "-" to set hour digits. Press "set" to confirm. Minute digits flash.
 - (iii) Press "+" or "-" to set minute digits. Press and hold "set" to confirm and go back to real time mode. Second digits return to 00.
- (5) Alarm and snooze On/Off
 - (i) Go to (2b), press and hold "set" to get into the alarm mode, Hour digits flash.
 - (ii) Press "+" or "-" to set hour digits. Press "set" to confirm. Minute digits flash.



- (iii) Press "+" or "-" to set minute digits. Press and hold "set" to confirm.
- (iv) When time is reached, ▲ flashes and beeping sound of alarm will last for 1 minute. Press any key to stop the alarm.
- (v) To get into the alarm with snooze mode, press "set" again, both ▲ & Z' flashes.
- (vi) When time is reached, ▲ flashed and stop it by pressing any key. While Z' start flashing. Snooze will sound for every 5 minutes and repeat for 5 times.
- (vii) Press "set" to cancel both function mode ▲ & Z'.
- (viii) Press "+" and "-" to return to the real time mode.



- (6) Timer Set (23:59:59)

Go to (2c), "▼" flashes. Time digits "0:00:00" show on the display.
- (7) Count up
 - (i) Press "mode" to start count up.
 - (ii) Press "mode" to pause/stop and re-start.
 - (iii) May press together "+" and "-" to go to other time mode during counting while the "▼" flashes during counting.
- (8) Count down
 - (i) Press and hold "set". Hour digits flash. Press "+" or "-" to set hour digit. Press "set" to confirm. Minute digits flash.
 - (ii) Press "+" or "-" to set minute. Press "set" to confirm. Second digits flash.
 - (iii) Press "+" or "-" to set second. Press "set" to confirm.
 - (iv) When setting is confirmed, all digit stop flashing and all are set well.

(4) Language for Day and Calendar set

- (i) Go to (2a), "d/m" or "m/d" shows.
 - (ii) Press and hold "set", display shows "E" representing English for day showing.
 - (iii) Press "+" or "-" to select the language. Display show as following: "E" → "D" → "F" → "I" → "S" → "E"
- You can select E for English, D for German, F for French, I for Italian or S for Spanish. They are shown in the language chart below.



Language	Day-of-the-week						
	Mon	Tues	Wed	Thur	Fri	Sat	Sun
English E	Mo	Tu	We	Th	Fr	Sa	Su
German D	Mo	Di	Mi	Do	Fr	Sa	So
French F	Lu	Ma	Me	Je	Ve	Sa	Di
Italian I	Lu	Ma	Me	Gi	Ve	Sa	Do
Spanish S	Lu	Ma	Mi	Ju	Vi	Sa	Do


- (iv) Press "set" to confirm and month digits flash first. Press "+" or "-" to set month. Press "set" to confirm. Then date digits flash.
- (v) Press "+" or "-" to set date. Press and hold "set" to confirm and go back to real time mode.
- (vi) Go to (2b). "yr" shows and 4 places digit shows also.
- (vii) Press and hold "set", the last 2 digits of year flash (the first 2 digits "20" will not flash). Press "+" or "-" to set year from "00" to "59".
- (viii) Press and hold "set" to confirm and go back to real time mode.

(G) Weather forecast

To look for Weather forecast

(It will be shown on the display by all time. Includes icons of the following)

- (i) sunny ☀
- (ii) partly cloudy ☁☀
- (iii) cloudy ☁
- (iv) rainy ☁☔
- (v) thunder storm ☁⚡
- (vi) moon and star ★ * ○




Backlight

- (i) Press "B/L" to turn on the backlight.
- (ii) Press again to switch off. Or it will turn off automatically after 10 seconds.

Battery Replacement

Turn the Main Unit over. Use a coin or similar opener to open cover. Insert a new batteries (2 x 3 volts "CR2032" size or equivalent) as the direction indicated. Close the cover.




- (v) When all digits are set well. Press "mode" to start count down.
 - (vi) Press "mode" to pause and re-start.
 - (vii) During counting, may press together "+" and "-" to go to other time function and "▼" flashes during count down.
 - (viii) When time is reached, it sounds for 1 minute and digit remain "0:00:00". Or press any key to stop beeping when time is reached.
 - (ix) Press "mode", the last setting will display. Simply press "mode" again to start count down again.
- (9) Timer clear
 - (i) In timer "▼" mode, press "mode" to pause counting. Then press "set" to clear. Timer digits return to "0:00:00"

(F) Calendar

To look for CALENDAR information:

- (1) Press "mode" to CAL mode. CAL will appear.
- (2) CAL mode includes :
 - (a) date and month showing (d/m or m/d) with day
 - (b) year showing (2000-2059)

To switch between (a) and (b), press "+" and "-" together.
- (3) Switchable d/m or m/d
 - (i) Go to (2a), press together "set" and "+" to switch between "d/m" or "m/d".



Maintenance/ Precautions

- Do not leave the Main Unit exposed to direct sunlight when the unit is not in use.
- Do not disassemble the Main Unit and sensor.
- Check relative position of sensor periodically.
- For cleaning, use neutral detergent on soft cloth, and wipe off later with dry cloth. Do not apply paint thinner, benzine, or alcohol, to avoid damages on the surface.
- If there is mud, sand or clog-like between the button and the body, the movement of the button may be disturbed. Softly wash away such objects with water.

Specification

Air Pressure
 Pressure Range: 300 ~ 1100mb (hPa); 8.85inHg ~ 32.45inHg
 Resolution: 1 mb/hPa; 0.01inHg
 Sensing Time: 15 minutes

Altitude
 Altitude Range: -700m ~ +9000m; -2296ft ~ +29520ft
 Resolution: 0.1m for -500.0m to 999.9m; otherwise 1m
 Sensing time: 2 sec
 (Sensing time under sleep mode is 15 minutes)

Temperature
 Temperature range: -10°C ~ +60°C or +14°F ~ +140°F
 Resolution: 0.1°C or 0.1°F
 Sensing Time: 1 min

Direction
 Range: 0-359°
 Resolution: 1°
 Sensing time: 1 sec for 1 min
 Unit: whole circle bearing, e.g. 255° (or compass bearing e.g. S75°W (=255°))

**HAND HELD
DIGITAL
BAROMETER**