



IN/OUT THERMOMETER WITH WATERPROOF PROBE

USER'S MANUAL



AQ150

Please read this manual carefully and thoroughly before using this product.

TABLE OF CONTENTS

Introduction	3
Key Features	4
What's In the Blister Pack	4
Product Overview	5 – 6
Setup Instructions	6 – 8
Activate the Thermometer	6 – 7
Choose a Temperature Unit	7
Mount the Display Unit	7 – 8
Extend and Secure the Probe	8
Operating Instructions	9 – 11
Displaying Real-time Temperature	9
Displaying MAX and MIN Temperatures	9
Setting High and Low Temperature Alarms	10 – 11
Specifications	12
Maintenance Tips	13
Warranty Information	13
Return for Repair Policy	14

INTRODUCTION

Thank you for purchasing General Tools & Instruments' AQ150 In/Out Thermometer with Waterproof Probe. Please read this user's manual carefully and thoroughly before using the product.

The AQ150 has two separate temperature sensors: one inside the display unit and the other inside a remote probe at the end of a 10 ft. (3m) long detachable cable. The remote circuit can be configured to sound an alarm when the temperature it senses rises above or falls below a set limit. This technology makes the AQ150 suitable for three different kinds of service:

- **Maintaining the water temperature of an aquarium.** In this application, the display unit is magnetically attached to the frame of the aquarium and the remote probe is attached by suction cup to the inside of a glass wall below the water level. The high and low alarms would both be set to keep the water temperature within a band that is healthy for fish.
- **Monitoring food temperature.** The dual alarms make it possible to track the temperature of a refrigerated case or heating table. Magnets on the back of the display unit could be used to attach it to a metal part of the case or table. The high temperature alarm would be used to guarantee that cold beverages and cold or frozen food remain that way. Use of the low temperature alarm would ensure that hot food remains above a certain temperature, keeping it safe to eat.
- **Comparing indoor and outdoor temperature.** The cable of the remote probe is thin enough to fit under a window. A front panel switch lets you toggle the display between **INT** (interior) and **EXT** (exterior) measurements.

KEY FEATURES

- Displays ambient or remote (INT or EXT) temperature
- Tracks MAX and MIN temperatures
- High and low temperature alarms for remote circuit
- °C/°F button
- Backlit LCD and detachable cable of remote probe
- Foldaway stand and magnets on back of display unit
- Includes battery and mounting hardware
- CE approved

WHAT'S IN THE BLISTER PACK

The thermometer comes in a blister pack along with:

- A remote probe at the end of a detachable cable
- A suction cup for mounting the probe inside an aquarium or on a window
- A plastic bracket and screw for attaching the probe to wood
- Two Velcro strips for mounting the display unit
- (1) preinstalled “CR2032” battery with an activation tab
- This user's manual

PRODUCT OVERVIEW

Fig. 1 shows the LCD and controls on the front of the AQ150. Fig. 2 shows the key areas and components on the back of the unit.

Fig. 1. The controls and indicators on the front of the AQ150




1. LCD. Display shown indicates that the current (real-time) temperature sensed by the remote (**EXT**) probe is 82.2°F.
2. **Max/Min** button. Switches display out of real-time mode to show maximum and minimum temperatures recorded since the unit's battery was installed or its memory was reset.
3. **Ext/Int** button. Toggles display between internal and external temperature sensors.
4.  button. Used to arm and disarm alarm and set high and low temperature alarm limits.
5.  button. When pressed and held, turns display backlight on. When released, turns backlight off.
6. Remote temperature-sensing probe at the end of a detachable 10 ft. (3m) long cable.



Fig. 2. The back of the AQ150

- 7. Foldaway stand for table or desktop mounting
- 8. Display unit Velcro mounting area
- 9. Mounting magnets
- 10. °C /°F button. Used to select displayed temperature unit and set high and low temperature alarm limits
- 11. Alarm speaker
- 12. Battery compartment



SETUP INSTRUCTIONS

ACTIVATE THE THERMOMETER

If you are reading this, you have already removed the unit, the detachable probe, the suction cup and the plastic bag of mounting hardware from the bubble-wrap bag. At this time, **DO NOT** remove the twist tie keeping the 10-ft. probe cable in a neat bundle.

To activate the thermometer, open the battery compartment in the back of the unit (Fig. 2, Callout 12) by lifting the left side of the hinged door with your fingertip. Remove the battery activation tab. The beeper will sound quickly four times. Discard the tab and swing the battery compartment cover shut.

CHOOSE A TEMPERATURE UNIT

Before proceeding, remove the protective plastic film covering the display. Then turn the unit over and press the red °C/°F button (Fig. 2, Callout 10) to select a Celsius (°C) or Fahrenheit (°F) temperature unit. °C is the default setting.

MOUNT THE DISPLAY UNIT

To leave the unit free to move on a horizontal surface, lift the foldaway stand on the back of the unit (Fig. 2, Callout 7) by placing your fingertip in the recess adjacent to the Velcro mounting area.

To attach the unit to the metal frame of an aquarium, refrigerated case or heating table, use the two magnets on the top edge of the back of the case.

To attach the unit to a wall or any non-metal surface:

- 1) Remove the two Velcro strips from the mounting hardware bag.
Do not separate them.
- 2) Remove the paper backing from one strip and press its exposed sticky side into the unit's recessed rectangular mounting area (Fig. 2, Callout 8).
- 3) Remove the paper backing from the other strip.
- 4) Press the unit against the wall at the desired position.

To detach the unit (to change the battery, change the temperature unit, or reset the high and/or low alarm limits), grab it and pull until the two Velcro strips separate.

EXTEND AND SECURE THE PROBE

Remove the twist tie keeping the probe cable in a bundle. Extend the probe cable to the desired length.

To install the remote probe in an aquarium,

- 1) Slide the probe tip through the hole in the base of the suction cup.
- 2) Press the suction cup firmly against the glass inside the aquarium about 4 in. (100mm) below water level.

To attach the probe to the inside of a refrigerated case or heating table, or to the outside of a window,

- 1) Slide the probe tip through the hole in the base of the suction cup.
- 2) Moisten the inside of the suction cup and press it firmly against the inside frame or glass of the refrigerated case, heating table or window.

To attach the probe to a wooden outside window frame or apron,

- 1) Slide the probe into the channel of the supplied black plastic bracket. Push the probe until its tip reaches the end of the channel.
- 2) Using the supplied Phillips-head wood screw, secure the bracket to the frame or apron.

OPERATING INSTRUCTIONS

DISPLAYING REAL-TIME TEMPERATURE

To display the ambient temperature at the display unit, press the **Ext/Int** button until **INT** appears at the right of the readout. To display the temperature sensed by the probe, press the **Ext/Int** button until **EXT** replaces **INT**.

DISPLAYING MAX AND MIN TEMPERATURES

Pressing the **Max/Min** button briefly (for less than 1 second) cycles through three readings: maximum, minimum and real-time temperatures. After the unit is activated, the initial readout is the real-time **EXT** temperature.

Press the **Max/Min** button once and the display will switch to the highest (maximum) temperature recorded since the unit's battery was installed or since the memory was reset. The term **MAX** will appear, flashing, at the left of the display.


Press the **Max/Min** button again and the display will switch to the lowest (minimum) temperature recorded since the unit's battery was installed or since the memory was reset. The term **MIN** will appear, flashing, at the left of the display.

Press the **Max/Min** button a third time and the display will return to showing the real-time **INT** or **EXT** temperature.

To reset the Max/Min memory, press the **Max/Min** button and hold it for at least 1 second.



SETTING HIGH AND LOW TEMPERATURE ALARMS


Temperature alarms can only be set for the sensor in the external probe. You cannot set alarms with the display unit mounted on a wall or frame because setting alarm levels requires access to the °C/°F button on the back of the unit. Before proceeding, detach the unit by pulling it off the metal frame or separating the Velcro mounting strips.


1. To set either or both alarms, begin by pressing the  button and holding it for 3+ seconds.

This will cause the display to begin flashing a value, along with the non-flashing terms **HIGH** and **EXT**. The term **AL** will also appear (not flashing), in the lower left corner. You now have 1 minute to set the high temperature alarm limit at any level within the remote probe's range of -58° to 158°F (-50° to 70°C) by following Step 2. If you do not wish to set the high temperature alarm, skip ahead to Step 3 below.

2. To set the high temperature alarm limit, hold the unit in one hand in front of your face. With your other hand, reach behind the unit and begin pressing the °C/°F button. Each press of the button increases the alarm temperature level (as shown on the display) by 1.8° with the display in °F mode and by 1° with the display in °C mode. To speed up the process by increasing the temperature in multiple steps, press and hold the °C/°F button.

When the desired high temperature alarm level is displayed, press the  button to store the setting. The beeper will sound once and the display will begin to flash a value, along with the terms **LOW** and **EXT**. You now have 1 minute to set the low temperature alarm level at any value within the remote probe's range of -58° to 158°F (-50° to 70°C). If you do not wish to set the low temperature alarm, press the  button again and skip ahead to Step 4 on next page.

- 3. To set the low temperature alarm limit**, follow the instructions in Step 2 on previous page, substituting “low” for “high” and “decreases/decreasing” for “increases/increasing.”
- 4.** When the desired low and/or high temperature alarm level(s) is/are displayed, press the  button to store the setting(s).

Once you have stored the high and/or low alarm temperature level(s), the display will stop flashing and resume showing the **Int** or **Ext** temperature it was showing when the alarm setting process began. However, the term **AL** will remain in the lower left corner. Whenever the display is not flashing, the  button serves as the vehicle for arming and disarming the alarms. If **AL** appears on the display, any alarms are armed. If it does not, any alarms are disarmed.

Note: If you set a high alarm limit that is below the real-time **Ext** temperature, the alarm will sound within 10 seconds of storing the setting. The alarm will also sound if you set a low alarm limit that is above the real-time **Ext** temperature.

To stop the alarm from sounding, press any button.

SPECIFICATIONS

Ambient Temperature Range:	14° to 122°F (-10° to 50°C)
Remote Temperature Range:	-58° to 158°F (-50° to 70°C)
Measurement Accuracy:	±1°F (0.5°C) from -4° to 122°F (-20° to 50°C); ±1.8°F (±1°C) outside this range
Display Resolution:	0.1° (C or F)
Sampling Period:	10 seconds
Probe Cord Length:	10 ft. (3m)
Display Size:	1.88 x 0.82 in. (48 x 21mm)
Digit Height:	5/8 in. (16mm)
Dimensions:	2.9 x 2.1 x 0.7 in. (73 x 52 x 18mm)
Weight:	3.76 oz. (106g)
Power Source:	1 “CR2032” battery (included)

MAINTENANCE TIPS

Although the sensor, probe and cable are waterproof, the display unit is NOT waterproof. Do not install the display unit outdoors.

To clean the display unit, wipe it gently with a dry or damp cloth. Avoid using chemical cleaners.

To replace the battery, follow the instructions at the top of p. 7.

WARRANTY INFORMATION

General Tools & Instruments' (General's) AQ150 In/Out Thermometer with Waterproof Probe is warranted to the original purchaser to be free from defects in material and workmanship for a period of one year. Subject to certain restrictions, General will repair or replace this instrument if, after examination, the company determines it to be defective in material or workmanship.

This limited warranty does not apply to damages that General determines to be from an attempted repair by non-authorized personnel or misuse, alterations, normal wear and tear, or accidental damage. The defective unit must be returned to General Tools & Instruments or to a General-authorized service center, freight prepaid and insured.

Acceptance of the exclusive repair and replacement remedies described herein is a condition of the contract for purchase of this product. In no event shall General be liable for any incidental, special, consequential or punitive damages, or for any cost, attorneys' fees, expenses, or losses alleged to be a consequence of any damage due to failure of, or defect in any product including, but not limited to, any claims for loss of profits.

RETURN FOR REPAIR POLICY

Every effort has been made to provide you with a reliable product of superior quality. However, in the event your instrument requires repair, please contact our Customer Service to obtain an RGA (Return Goods Authorization) number before forwarding the unit via prepaid freight to the attention of our at this address:

General Tools & Instruments
80 White Street
New York, NY 10013
212-431-6100

Remember to include a copy of your proof of purchase, your return address, and your phone number and/or e-mail address.



Specialty Tools & Instruments

GENERAL TOOLS & INSTRUMENTS

80 White Street

New York, NY 10013-3567

PHONE (212) 431-6100 FAX (212) 431-6499

TOLL FREE (800) 697-8665

e-mail: sales@generaltools.com

www.generaltools.com

AQ150 User's Manual

Specifications subject to change without notice

©2012 GENERAL TOOLS & INSTRUMENTS

NOTICE - WE ARE NOT RESPONSIBLE FOR TYPOGRAPHICAL ERRORS.

MAN#AQ150 9/25/12