

Assembly Instructions For Crossleg Table With 2 Benches

Tools Needed:

Hammer For Light Tapping
Drill & Bit Set (Optional)

Parts List:

Table Top (1)
Bench Tops (2)
Table Leg Assemblies (2)
Bench Leg Assemblies (4)

Hardware:

1/4" x 2" Bolts (12)
1/4" x 2-1/2" Lag Screws(6)
Allen Wrench (1)

- Step 1** Lay out and identify all the parts and pieces.
- Step 2** Lay the table top upside down on a clean surface. Take the long leg assemblies and separate them by creating an X. Taking the notched ends of the legs, attach them to the 2x2 on the table with the brace on the inside of the legs . Be sure the legs are attached one on either side of the 2x2. Align the predrilled holes in the legs with the threaded inserts in the 2x2. Put a 2" bolt through the legs, turn them into the inserts and tighten with the Allen wrench. The bolts will go in opposite ways, they always go through the legs first.
- Step 3** Next insert a 2-1/2" lag screw into the holes in the 45° braces. Tap with the hammer to start them in. They can be turned in with the Allen wrench by using the long end of the Allen wrench & holding the short end in the palm of your hand & applying downward pressure while turning. Most drill bit sets will also have a bit that can be used with a drill or screwdriver to turn them in. Make sure you attach the brace to a solid piece of the seat and not the crack between the boards. (The bench and the legs do not have predrilled holes to attach the braces as the lag screws are self drilling and will not crack the bench or the legs. The lag screws will not pull tight with predrilled holes). **Do not over tighten the lag screws.**
- Step 4** (For benches only) Set your table upright and lay the benches face down on a clean surface. Follow the same procedure as in steps 2 and 3 above to attach the bench legs.

If you ordered the table only skip Step 4.