



Scan for full manual

VM-50AN Quick Start Guide


This guide helps you install and use your VM-50AN for the first time.

Go to www.kramerav.com/downloads/VM-50AN to download the latest user manual and check if firmware upgrades are available.

Step 1: Check what's in the box

- ✓ VM-50AN 1:5 Audio Distributor
- ✓ Power supply (12V DC)
- ✓ 4 Rubber feet
- ✓ 1 Quick start guide

Step 2: Get to know your VM-50AN



#	Feature	Function
1	POWER Switch	Illuminated switch supplying power to the unit
2	INPUT MODE BAL/UNBAL Button	When released, selects the balanced stereo audio input when pushed in, selects the unbalanced stereo audio
3	RIGHT LEVEL Trimmer	Adjusts the right output signal level (use a small screwdriver)
4	LEFT LEVEL Trimmer	Adjusts the left output signal level (use a small screwdriver)
5	INPUT 3.5mm Mini Plug Connector	Connects to the unbalanced audio source
6	INPUT Terminal Block Connector	Connects to the balanced audio source
7	OUT 3.5mm Mini Plug Connector	Connects to the unbalanced audio acceptor (from 1 to 5)
8	OUT Terminal Block Connector	Connects to the balanced audio acceptor (from 1 to 5)
9	12 VDC 200mA	+12V DC connector for powering the unit

Step 3: Mount VM-50AN

Install VM-50AN using one of the following methods:


- Attach the rubber feet and place the unit on a flat surface.
- Mount the unit in a rack using the recommended rack adapter (see www.kramerav.com/product/VM-50AN).



- Ensure that the environment (e.g., maximum ambient temperature & air flow) is compatible for the device.
- Avoid uneven mechanical loading.
- Appropriate consideration of equipment nameplate ratings should be used for avoiding overloading of the circuits.
- Reliable earthing of rack-mounted equipment should be maintained.

Step 4: Connect inputs and outputs

Always switch OFF the power on each device before connecting it to your VM-50AN.



To achieve specified extension distances, use the recommended Kramer cables available at www.kramerav.com/product/VM-50AN. Using third-party cables may cause damage!

Step 5: Connect power

Connect the 12V DC power adapter to VM-50AN and plug it into the mains electricity.

Safety Instructions (See www.kramerav.com for updated safety information)



Caution:

- For products with relay terminals and GPIO ports, please refer to the permitted rating for an external connection, located next to the terminal or in the User Manual.
- There are no operator serviceable parts inside the unit.

Warning:

- Use only the power cord that is supplied with the unit.
- Disconnect the power and unplug the unit from the wall before installing.

Step 6: Operate VM-50AN

Set the input mode to balanced or unbalanced stereo.

Using a small screwdriver, adjust the output level.

