

IR REMOTE CONTROL GUIDE

Fixed 4K2K 16x16 & 16x32 HDMI Matrix Switcher



*Please NOTE: The EDID is not functional on this IR remote control for this 16x16 HDMI Matrix Switcher, we recommend using the WEB/APP/BUTTONS

Inputs Switch:

number(0~9) ---> SWITCH ----> number(0~9) ---> ENTER

Eg: input 1 to output 1:

1--> SWITCH ----> 1 ---> ENTER

Inputs Switch to multiple outputs:

number(0~9) ---> SWITCH ----> number(0~9)-->ENTER-->
number(0~9)--->ENTER

Eg: input 2 to output 1,2,3,14:

2--> SWITCH ---> 1 ---> ENTER ----> 2 ---> ENTER ----> 3 ---> ENTER
----> 14 ---> ENTER

Inputs Switch to ALL outputs:

number(0~9) ---> SWITCH ----> ENTER

Eg: Input 1 to all outputs:

1 ---> SWITCH ----> ENTER

Scene Save(total 16 scenes):

number(0~9) ---> SAVE

Eg: Save the current switch to scene2:

2--> SAVE(The LCD Screen will show Save 02, DONE)

Scene Recall(total 16 scenes):

number(0~9) ---> RECALL

Eg: Recall the scene10:

10 --> RECALL(The LCD Screen will show Load 10, DONE)

