

## KEY FUNCTIONS

- ON/C** Turns the calculator on  
Clears all calculator contents  
(calculations, memory, etc.)
- M+** Adds the displayed value to  
the memory
- M-** Subtracts the displayed value from  
the memory
- MRC** First press recalls the memory total  
Second press clears the memory total

## AUTO POWER OFF

The calculator utilizes an auto power off feature which allows the elimination of the “power off” button. The calculator will automatically turn off after approximately six (6) minutes if no button has been pressed.

## BATTERY REPLACEMENT

The primary power for the calculator comes from the solar cell; however, the backup battery will provide power for low light conditions. A faint display, no display in low light conditions, and missing segments are all indications that the backup battery must be replaced. Remove the battery cover, located on the back of the unit. Remove the exhausted battery and replace it with a new #389 silver oxide battery. Make certain to insert the new battery with the positive “+” size visible. Replace the battery cover.

**BIG DIGIT  
SOLAR-POWERED  
CALCULATOR  
INSTRUCTIONS**