



# Digital Count-Down Timer

Extra loud audible alarm

Timer counts down from 19:59

**No. T1268**  
UPC 30030

**TIME**  
Instruments

3-13/16 x 5-9/16

T1268 - 040308 - FRONT - FINAL



**No. T1268**  
www.generaltools.com


User's Manual enclosed.

#### FEATURES:

- Easy operation
- Economy model
- Spring loaded clip converts to stand
- Magnet for metal surface attachment


#### SPECIFICATIONS:

- LCD size: 0.71" x 0.32" (18 x 8 mm)
- Display size: 0.71" x 0.32"
- Unit size: 2.44" x 1.97" x 0.47"
- Digit height: 0.25"
- Dimensions: 2.44" x 1.97" x 0.47" (62 x 50 x 12 mm)
- Weight: 1 oz. (28 g)
- Power source: 1 "LR44" battery (included)

 Avoid injury. Always wear OSHA/ANSI approved eye protection (goggles, face shield) when using tools. Evitez les blessures : Portez toujours une protection oculaire (lunettes ou masque facial) homologuée OSHA/ANSI quand vous utilisez des outils. Evite lesiones: Siempre use protección ocular aprobada por OSHA/ANSI (gafas de seguridad, protector facial) cuando utilice herramientas.

Made in China / Fabriqué en Chine / Hecho en China

©2008 GENERAL TOOLS & INSTRUMENTS™  
New York, NY 10013 Montreal, Canada H9R 1E1



6 81035 300301 5

3-13/16 x 5-9/16

T1268 - 040308 - BACK - FINAL



**No. T1268**  
USER'S MANUAL

#### INSTRUCTIONS:

##### TO SET TIMER:


- Press HOUR/CLEAR button to set desired hours.
- Press MINUTE button to set desired minutes.

##### TO START TIMER FUNCTION:

- Once desired time is shown on display, press START/STOP button to start timer counting down.
- Your timer will continue counting down until it reaches zero and the buzzer will sound unless it is manually stopped before then.

##### TO DISCONTINUE OR RESET TIMER:

- Should you wish to stop the timer before all of the time has elapsed press the START/STOP button. To clear the amount of time shown press the HOUR/CLEAR button.
- The timer can be temporarily stopped by pressing the START/STOP button. You can restart it by pressing the START/STOP button again.



Battery door



Spring loaded clip converts to stand  
Magnet for metal surface attachment

##### WHEN THE BUZZER GOES OFF:

- Press the HOUR/CLEAR button to turn off the buzzer.

##### TO INSERT THE BATTERY:

- Slide open battery hatch in direction shown by the arrow.
- Insert battery flat side up and close hatch.

##### BEFORE FIRST USE:

- Remove film from face showing 19:59.

www.generaltools.com

©2008 GENERAL TOOLS & INSTRUMENTS™  
New York, NY 10013 Montreal, Canada H9R 1E1

4 x 6 (FINAL FOLDED SIZE: 2 x 1-1/2)

T1268 - 040308 - MANUAL - FINAL