# WÖHLER



# UNIQUELY CLEAR VIEW

# Wohler VIS 350 Inspection System

Capitalize the first letter in each word



# Wohler VIS 350 Inspection System

### The intelligent camera head to your benefit

With the Wohler VIS 350 camera system, you have everything you need to inspect waste water pipes, flue gas and ventilation lines and industrial systems. With the pan & tilt camera head, the built-in transmitter and the Wohler L 200 Locator you can precisely locate the damage and accurately document the results of the inspection.

Wohler's camera system is both compact and safely housed in a plastic case for transport. The system consists of a 100 ft push rod cable with reel, a full color 1.5" pan and tilt camera and a large color monitor. The Wohler control panel ensures easy control of the camera head: The camera pans 360°, tilts 180° and offers the best-possible lighting to carry out an all-round inspection of the inside of the pipe. Particularly practical: After panning and tilting, the home function automatically aligns the camera angle to straight ahead with a simple push of a button. The ability to record videos allows the camera to capture exactly what it detects during the inspection. When damage is discovered, one quick press of a button is all that is required to capture and save a photo.

To be able to assess and specifically target repair work, we at Wohler have perfected the technique of precisely locating damage. The actual distance count and the position of the head are displayed in the monitor. This feature is beneficial when dealing with extensive networks of pipelines. The position and angle of the camera head is displayed on the monitor, at all times. Precise localization of the camera head is available with the Wohler L 200 Locator.





































- ▶ Position and digital distance counter of camera head indicated in the display
- ▶ Keep your sense of orientation with home function
- ▶ 4 hour flexibility 2 rechargeable batteries for lasting mobility
- ▶ Built-in transmitter with adjustable frequency enables precise localization of the camera head



The robust color camera head is waterproof to IP 67 rating. With a diameter of just 1.5" it easily negotiates bends in pipes of 2.5" and larger.



head through concrete and asphalt to save time and money in repairs.



The 360° pan- and 180° tiltable color camera head easily negotiates 90°



The Wohler L 200 Locator makes it possible to locate the camera head

2 | www.wohlerusa.com www.wohlerusa.com 3



Monitor	Dimensions housing	7" x 4.5" x 1.3"	
	TFT-display	7"/16:9 format	
	Video out	FBAS signal	
	Weight	1 lbs	
	Power supply	Space for 2 rechargeable batteries, each 12 V or via power pack	
	Battery operating time	Max. 2 rechargeable batteries each 120 mins. = 4 h (battery status in display)	
Wohler	Type	1/3" COLOR CMOS	
pan- and tiltable	Pixels	656 x 492 (NTSC)	
camera head 1.5"	Light sensitivity	0.5 Lux	
	Lens	f = 0.09", F = 2.5	
	Viewing angle	130°	
	Light source	12 white LEDs	
	Degree of protection	Waterproof to IP 67	
	Dimensions	1.5" x 2"	
	Weight	1 lbs	
	Operation temperature	32104 °F, RH 95 % MAX	
	Storage temperature	-4122 °F, RH 95 % MAX	
	Transmitter frequency	512 Hz / 8.9 kHz / 9.2 kHz	
Wohler	Туре	1/3" COLOR CMOS	
miniature camera head 1"	Pixels	768 x 576 (PAL) 656 x 492 (NTSC)	
	Light sensitivity	0.5 Lux	
	Lens	f = 0.09", F = 2.5	
	Viewing angle	145°	
	Light source	12 white LEDs	
	Degree of protection	Waterproof to IP 68	
	Dimensions	1" x 1.5"	
	Weight	0.5 lbs	
	Operation temperature	32104 °F, RH 95 % MAX	
	Storage temperature	-4122 °F, RH 95 % MAX	
	Transmitter frequency	512 Hz / 8.9 kHz / 9.2 kHz	
Push rod	Length	100 ft	
	Diameter	0.26"	
	Distance measurement	digital distance counter	

#### ★ Application

Analyze damage and inspect:

- ▶ Waste water lines of 2.5" and larger
- ▶ House connections up to 8"
- ▶ Flue gas systems of 2" and larger
- ▶ Ventilation lines of ventilation systems
- ► False ceilings, hollow spaces, shafts

#### ☆ Functionality

- ▶ Optics pan- 360° and tilt 180° facilitate maximum movement radius and ensure even the smallest damage does not remain hidden from your view
- Store video footage and photos on a SD Card 4 GB (Wohler VIS 350)
- ► Camera head with integrated transmitter facilitates location detection by the Wohler L 200 Locator
- Digital position and angle of the camera head displayed on the monitor
- ► Home function aligns the camera head to a straight position display parallel to the ground above
- ▶ Brightly illuminating color camera head, 2" in length and 1.5", easily negotiates tight bends
- Electronic distance counter with a resolution of 0.10 ft displayed on the monitor
- ▶ Bright TFT color monitor (tiltable and removable) supplies razor sharp images
- ▶ Battery operating time: 2 x 120 min. with 2 rechargeable batteries
- Fully equipped mobile solution in a robust plastic case

#### ♠ Data management

▶ Simply record and store photos and videos on a SD Card 4 GB (Wohler VIS 350) for documentation and archiving purposes for you and your customers

#### Q Localisation with Wohler L 200 Locator (optional)

- Transmitter integrated in camera head makes it possible to precisely locate the camera head
- ► Facilitates targeted repairs to damaged pipelines
- ► Telescopic holder makes it possible to locate damage under floors or in ceilings
- ► Powerful rechargeable battery
- ► Localization of 8.9 kHz and 9.2 kHz frequencies

4 | www.wohlerusa.com | 5

## Wohler L 200 Locator

Views through concrete and masonry

Inspecting pipes under the ground, in ceilings and walls is a daily routine for contractors. After the inspection, the next task is to locate the position of the damage accurately to be able to minimize repairs. The Wohler L 200 detects the transmitter, built into the camera head, to precisely locate the damage.



Contractors and their customers are able to save considerable time and money by utilizing video inspections to visualize leaks and document damaged or soiled sections of pipework. The Wohler L 200 Locator also locates the radio signals transmitted by the camera head of the precisely in a clear-cut graphic on the how the Wohler L 200 makes locating simple: The Locator can be attached to

a telescopic pole to make the search for the camera head as effective as possible. Guided close to the ground, along walls or below the ceiling, it locates the signals transmitted by the camera head. The user is guided by the bright color display throughout the locating process. Wohler VIS systems. Damage is displayed In addition, an acoustic signal is emitted and made audible via a loudspeaker display of the Locator to ensure it is or headphones. The on screen display discovered rapidly and marked. This is indicates the signal strength and direction to the camera head.











#### ▶ Locates radio signals transmitted by the camera head – rapidly pinpoints damage

- ► Transmitter frequency 512 Hz / 8.9 kHz / 9.2 kHz
- ► Easy to handle user guided via display throughout the locating process
- ▶ Bright, easy-to-read color display
- ► Telescopic pole easily track down damage anywhere

## **Kits**









		Wohler VIS 350 Inspection Camera	Wohler VIS 350 Inspection Camera	Wohler VIS 350 Inspection Camera	Wohler VIS 350 PLUS Inspection Camera
	camera head	1.5" fixed	1.5" detachable	1" / 1.5" detachable	1" / 1.5" detachable
Scope of delivery	Wohler VIS 350 Inspection Camera with digital distance counter	•	•	•	•
	Carrying case	•	•	•	•
	Wohler pan- and tiltable camera head 1.5", fixed	•			
	Wohler miniature camera head 1", detachable			•	•
	Wohler pan- and tiltable camera head 1.5", detachable		•	•	•
	SD Card 4 GB and Mini-USB cable	•	•	•	•
	7" TFT color monitor	•	•	•	•
	6 ft connection cable (removable monitor)	•	•	•	•
	100 ft push rod 0.26"	•	•	•	•
	5 plastic domes	•	•	•	•
	Anti-slide mat	•	•	•	•
	2 NiMH batteries with charger	•	•	•	•
	Wohler L 200 Locator				•
	P/N	7354	6352	8927	8931

6 | www.wohlerusa.com www.wohlerusa.com | 7

# © Wohler 03/2020 all rights reserved. Subject to changes, including of a technical nature. // #57746

# **Accessories**

Article description		P/N
WELL.	Wohler L 200 Locator for camera heads 1" / 1.5"  Scope of delivery: Wohler L 200 Locator, plastic case, USB power supply with Micro-USB	7430
<b>* 400</b>	cable, chalk (12 pcs. box, yellow), telescopic rod and headphones  Camera Roller Guide for camera heads and push rods	3681
<b>B</b>	Wohler Guidance Set 100 for camera head 1.5" Scope of delivery: protection sleeve with cut-out, roller guide and centering star	4240
	Guidance Sleeve with protection cage for camera head 1"	3847
<b>8</b>	Protection Sleeve with cutout for camera head 1.5"	2641
	Glass Dome for camera head 1.5"	3674
966b	Replacement Polycarbonate Dome for camera head 1.5" 10 pcs.	3675
4	Battery for Wohler VIS 2xx / 3xx	4715
	Power Supply for Wohler VIS 2xx / 3xx  18 V, 1.5 A, 100 – 240 V, 50 Hz, charge time 3 hours, for all countries	4798
	Car Charger for Wohler VIS 2xx / 3xx	3169
	Wohler VIS Camera Trolley Set for camera heads  Scope of delivery: Wohler VIS Camera Trolley, camerahead-holder, storage bag, stabilization sleeve for	4753
/	light ring (can only be used in combination with supplementary light ring)  Wohler Light Ring 1" / 1.5"  for camera heads 1" / 1.5"	8894
	light ring with 18 white LEDs, outer 2.1", detachable	

