Instructions for 46", 58", 70", & 94" Red Cedar Contoured Backed Bench

Item: ELY46CTT2B2BBCVD, ELY58CTT2B2BBCVD, ELY70CTT2B2BBCVD, ELY94CTT2B2BBCVD, ELY46CTT1B1BBCVD, ELY58CTT1B1BBCVD, ELY70CTT1B1BBCVD, ELY94CTT1B1BBCVD, ELY46CTT4BBCVD, ELY58CTT4BBCVD, ELY70CTT4BBCVD, ELY94CTT4BBCVD

Tools Required for Assembly

7/16" Socket or Adjustable Wrench
2# Squarehead Bit (included)
Hammer for tapping bolts and screws.

Hardware List

8- 1/4 x 3" Hex Bolts
8- 1/4" Hex Nuts
16- 1/4 x 1" Fender Washers
4- 3" Screws
4- 2 1/2" Screws

Hex Bolts

Screw

Fender Washer

Nut

Pre-drilled Hole

Parts List

1- Bench Top
1- Bench Back
2- Bench Legs

This Item can be found on www.OutdoorFurniturePlus.com

Call **877-595-8543** to order.

Step 1:
Lay the table top upside down on a clean flat surface. Place each leg on the outside, aligning it with the pre-drilled holes. Tighten the bolts.

Step 2:
Now put the 3" screws in the small pre-drilled holes.

Step 3:
Tip the bench on its side and place the bench back on the outside of the bench, align holes, tighten bolts, and put 2 1/2" screws in small pre-drilled holes.

Instructions for 46", 58", 70", & 94" Red Cedar Contoured Backed Bench

Item: ELY46CTT2B2BBCVD, ELY58CTT2B2BBCVD, ELY70CTT2B2BBCVD, ELY94CTT2B2BBCVD, ELY46CTT1B1BBCVD, ELY58CTT1B1BBCVD, ELY70CTT1B1BBCVD, ELY94CTT1B1BBCVD, ELY46CTT4BBCVD, ELY58CTT4BBCVD, ELY70CTT4BBCVD, ELY94CTT4BBCVD



Chickadee Table Assembly Instructions

Item: ELY46CTT4BBCVD, ELY58CTT4BBCVD, ELY70CTT4BBCVD, ELY94CTT4BBCVD

Tools Required for Assembly

7/16" Socket or Adjustable Wrench
2# Squarehead Bit (included)
Hammer for tapping bolts and screws.

Hardware List

8- 2 1/2" Hex Bolts
8- Hex Nuts
24- 1/4 x 1" Fender Washers
8- 1/4 x 2 1/2" Lags

Hex Bolts

Screw

Fender Washer

Nut

Pre-drilled Hole

Parts List

1- Table Top
4- Table Legs



Step 1:
Lay the table top upside down on a clean flat surface. Place each leg on the outter side into the notched out cross member using the 2 1/2" bolt.

Step 2:
Next put the 2 1/2" Lags through the side rail piece into the leg.

Step 3:
Repeat with each leg.

Instructions For 32”, 46”, 58”, 70”, & 94”
Red Cedar Contour Bench

Item: ELY46CTT4B-2CVD, ELY58CTT4B-2CVD, ELY70CTT4B-2CVD, ELY94CTT4B-2CVD, ELY46CTT2B2BBCVD, ELY58CTT2B2BBCVD, ELY70CTT2B2BBCVD, ELY94CTT2B2BBCVD, ELY46CTT1B1BBCVD, ELY58CTT1B1BBCVD, ELY70CTT1B1BBCVD, ELY94CTT1B1BBCVD

Tools Required for Assembly

7/16” Socket or Adjustable Wrench
2# Squarehead Bit (included)
Hammer for tapping bolts and screws.

Hardware List

8- 1/4 x 3” Hex Bolts
8- 1/4” Hex Nuts
16- 1/4 x 1” Fender Washers
8- 3” Screws

Hex Bolts



Screw

Fender Washer

Nut

Pre-drilled Hole

Parts List

1- Bench Top
4- Bench Legs





Step 1:
Lay the bench with the top upside down on a clean flat surface. Place each bench leg on the outside aligning with the predrilled holes. Tighten the bolts.

Step 2:
Next put the 3” screws in the small predrilled holes. It is easier to put the bolt part of the way into the predrilled hole and then tap the rest of the way with a hammer.

Step 3:
Repeat with each leg.