


# RT248, RCT248, RRT248, RBT248


Round 48" Table  
*Assembly Instructions*






To watch a video of this assembly,  
visit [youtube.com/polywood](https://www.youtube.com/polywood)

## TOOLS




4mm T-handle  
Hex Key (included)




3/8" Wrench  
(not included)

## PARTS




**A** x 8




14 X 2.50 HEX WASHER T-A ALCHM

**B** x 4




.27 x 3 SOCKET WASHER A

**C** x 4




1/4-20 x 3-1/4 WASHER SHCS

**1**




**3**



Something missing? Call (877) 457-3284


2

Make sure label  
faces outwards




NOTE: Do not over-tighten

NOTE: Do not over-tighten




4



Removable table plug  
included in table

# POLYWOOD

## Assembly Instructions



**NO ASSEMBLY REQUIRED**

### TD200 Dining Arm Chair



#### ..... **20-Year Warranty** .....

To view our full warranty, please visit  
[polywoodoutdoor.com/warranty](http://polywoodoutdoor.com/warranty)

Easily register your product using  
one of the methods below:


**Text POLYWOOD to 71403**  
Receive a link to register online

— or —

**Register on our website**  
[register.polywoodoutdoor.com](http://register.polywoodoutdoor.com)

— or —

**Send a Picture**  
Take a photo of the icon below and  
text it to 71403 (US only)





## ..... Having Trouble? .....

If you have questions or concerns regarding assembly instructions or missing parts, please contact us at (877) 457-3284 or email [support@polywoodoutdoor.com](mailto:support@polywoodoutdoor.com)



## ..... Share your space .....

We love to see where our furniture ends up — snap a pic and share it on Instagram or Facebook!  
**#polywood**



## ..... Watch & Learn .....

For assembly videos and more, visit [youtube.com/polywood](https://youtube.com/polywood)



## ..... Cleaning Tips .....

Even POLYWOOD gets dirty — here are some ways to help keep it clean:

### For a quick clean:

Simply wipe down with soap and water.

### For a deeper clean:


You'll need:

- » 1/3 bleach and 2/3 water solution
- » clean cloth
- » soft bristle brush

Wipe on solution with your cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.

# POLYWOOD

## Assembly Instructions



**NO ASSEMBLY REQUIRED**

### **TD100** La Casa Cafe Dining Side Chair



#### ..... **20-Year Warranty** .....

To view our full warranty, please visit  
**[polywoodoutdoor.com/warranty](http://polywoodoutdoor.com/warranty)**

Easily register your product using  
one of the methods below:


**Text POLYWOOD to 71403**  
Receive a link to register online

— or —

**Register on our website**  
**[register.polywoodoutdoor.com](http://register.polywoodoutdoor.com)**

— or —

**Send a Picture**  
Take a photo of the icon below and  
text it to 71403 (US only)





## ..... Having Trouble? .....

If you have questions or concerns regarding assembly instructions or missing parts, please contact us at **(877) 457-3284** or email [support@polywoodoutdoor.com](mailto:support@polywoodoutdoor.com)



## ..... Share your space .....

We love to see where our furniture ends up — snap a pic and share it on Instagram or Facebook!  
**#polywood**



## ..... Watch & Learn .....

For assembly videos and more, visit [youtube.com/polywood](https://youtube.com/polywood)



## ..... Cleaning Tips .....

Even POLYWOOD gets dirty — here are some ways to help keep it clean:

### For a quick clean:

Simply wipe down with soap and water.

### For a deeper clean:

You'll need:

- » 1/3 bleach and 2/3 water solution
- » clean cloth
- » soft bristle brush

Wipe on solution with your cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.