Trex Outdoor Furniture

Assembly Instruction Packet For: TXC71 and TXC47

This Item can be found on www.OutdoorFurniturePlus.com

Call 877-595-8543 to order.

Sort Boxes


Items are shipped in multible boxes


Sections needed for SOFA

box - TXC23R box - TXC23C box - TXC23L


Sections needed for LOVESEAT

box - TXC23R box - TXC23L





page 1 10/29/2010



Sofa Assembly note: use course thread on 1,2,3,4,5 Repeat until all three seats and backs are assembled Attach Seat support using (2) 3" chair screws/ Attach Back to Seat using (2) 3" chair screws Attach Sideframe and Back rail using (4) 3" chair screws Left Sideframe and Back rail to Seat

