




Installation Instructions

M 6160 TC

M 6260 TC

Caring for the environment

Disposal of packaging material

The cardboard box and packing materials protect the appliance during shipping. They have been designed to be biodegradable and recyclable.

Ensure that any plastic wrappings, bags, etc. are disposed of safely and kept out of the reach of children.

Danger of suffocation! Ensure that any plastic wrap is disposed of safely and kept out of the reach of children.

Danger of suffocation!

Disposal of your old appliance

Old appliance may contain materials that can be recycled. Please contact your local recycling authority about the possibility of recycling these materials.

Before discarding an old appliance ensure that it presents no danger to children while being stored for disposal. Unplug it from the outlet, cut off its power cord and remove any doors to prevent hazards.

 **CAUTION:** Before servicing, disconnect the power supply by either removing the fuse, shutting off the power main or manually "tripping" the circuit breaker.

Installation work and repairs should only be performed by a qualified technician in accordance with all applicable codes and standards. Repairs and service by unqualified persons could be dangerous and the manufacturer will not be held responsible.

Before connecting the appliance to the power supply, make sure that the voltage and frequency listed on the data plate correspond with the household electrical supply. This data must correspond in order to prevent machine damage. Consult an electrician if in doubt.

Only operate the appliance after it has been installed into cabinetry.

The appliance must be plugged into an appropriate outlet that is installed and grounded in accordance with all local codes and ordinances.

Power supply

The microwave comes equipped with a power cord with a NEMA 5-15 P molded plug ready for connection to a:

120 V, 15 A, 60 Hz power supply.

WARNING: THIS APPLIANCE MUST BE GROUNDED

Installer:

Please leave these instructions with the consumer.



NEMA 5-15P, 15 amp, L1, N, G

Installation

When installing the microwave oven, ensure that there is unhindered ventilation at the front of the appliance.
Do not block the ventilation slots with any objects.



When transporting the microwave oven, do not carry the appliance by the door handle. Doing so may damage the door.
Use the handle recesses on the sides of the casing.

Installation dimensions




Installation instructions


The microwave oven may not be operated until it has been properly installed in a cabinet.



- Slide the microwave oven into the cabinet space, and pull the cable with the plug through the rear wall of the cabinet.



Installation



- Align the appliance.
- Open the microwave door and screw the appliance into the side walls of the cabinet using the screws provided.

Please have the model and serial number
of your appliance available before
contacting Technical Service.



U.S.A.

Miele, Inc.

National Headquarters

9 Independence Way
Princeton, NJ 08540
Phone: 800-843-7231
609-419-9898
Fax: 609-419-4298
www.mieleusa.com

Technical Service & Support Nationwide

Phone: 800-999-1360
Fax: 888-586-8056
TechnicalService@mieleusa.com

Canada

Importer
Miele Limited

Headquarters and Miele Centre

161 Four Valley Drive
Vaughan, ON L4K 4V8
www.miele.ca

Customer Care Centre

Phone: 800-565-6435
905-532-2272
customercare@miele.ca

Germany

Manufacturer

Miele & Cie. KG
Carl-Miele-Straße 29
33332 Gütersloh



M 6160 TC, M 6260 TC



en - US, CA, MX

M.-Nr. 09 798 370 / 00