

OI-2100-DOCK Quick-Start Guide

Step 1: Check Gas and Pressure Gauge

Gas Bottle:

Insert a bottle of calibration gas, making sure to check the expiration date and gas type on the bottle before inserting.

Pressure Gauge:

Tighten until a reading appears on the pressure gauge.

- “0” (empty) to “500” (full) PSI-58 L bottles
- “0” (empty) to “1,000” (full) PSI-116 L bottles

Step 2: Performing a Bump Test

Powering On:

To turn on the OI-2100-DOCK, press the “Bump Test” button. The power light will turn **GREEN** when the unit is ready for use.

Inserting a Unit:

Power On the personal monitor(s). Place the unit(s) in any one of the four bays (see image).

Performing a Test:

Press the “Bump Test” button to start the test.

Step 3: Test Results

Each bay has a matching light. During the test, this light will be an orange/yellow color.

Pass:

A successful test will result in a **GREEN** light. Remove the unit and allow a few seconds for the gas reading to clear.

Fail:

A failed test will result in a **RED** light. If a unit has failed a test, recheck steps 1 and 2. If the unit fails again, please discontinue use and contact our service department.