




WINGSPAN : 1400mm (55.1 inches) LENGTH : 1280mm (50.4 inches) **WEIGHT** : 1850g (65.3 oz)

BATTERY : 14.8V Lithium Polymer Battery POWER SYSTEM: 15 Inch With Outrunner Brushless Motor : 4 Channel 5 Servos And 1 Brushless ESC **RC SYSTEM**

DIRECTIONS FOR ASSEMBLY AND ADJUSTMENT









- (1)(2) Assemble the main landing gear and cover with screw PM3*8 and PM3*35.
- (3) Install the main landing gear wheel.
- (4) Assemble the landing gear wheelpan with screw PA2.5*12.
- (5) Install the linkage connectors.
- (6) Connect the linkage rods.
- (7)(8) Glue the servo cover on the main wings.
- (9)(10) Insert the supporting rod into the right main wing.
- (11) Insert the main wings into the fuselage.
- (12)(13) Secure the main wings with screw PM3*40 and PM3*60.
- (14) Secure the tail wing onto the fuselage with screw PM3*40.
- (15) Install the vertical wing onto the tail wing.
- (16) Secure the vertical wing with screw PM3*60.

- (17) Install the plastic part for the vertical wing with screw PM3*25.
- (18) Secure the tail landing gear with screw PA2.5*10.
- (19)(20) Install the control wire for the tail landing gear.
- (21) Install the linkage rods for the rudder and elevator through the fuselage.
- (22)(23) Install the linkage connectors.
- (24) Adjust the linkage connectors for the rudder and elevator.
- (25) Secure the propeller.
- (26) Secure the spinner with screw PM4*60.
- (27) Secure the main landing gear with screw PM3*35.
- (28) Glue the exhaust pipe onto the bottom of the fuselage.
- (29) Secure the side force generator with screw PA1.7*8.





Lithium Polymer (LiPo) Battery Warnings

WARNINGS

- The product is not intended for those under 14 years of age without proper adult supervision. The product is not a toy. It is a precision machine requiring proper assembly and setup to avoid accidents and it is the responsibility of the owner to operate this product in a safe manner as it can cause serious personal injury and damage to property due to carelessness or misuse.
- The spinning rotors on this product can be dangerous! When operating/flying, always be aware of the spinning rotors. Be careful not to let them come close to your body, other people or loose clothing. Keep your hands, fingers and any articles of clothing away from the rotors.
- Do not attempt to disassemble or modify any of the product components without the assistance of an experienced RC user.
- Only use the correct type of battery to operate. Using any wrong type of battery will damage the product and
- possibly make it dangerous to operate
- The motor(s) may get hot during use. Always allow 10-15 minutes between each flight for the motor to cool down. This will prolong the life of your product.
- · Choose an appropriate operating site consisting of flat, smooth ground, and clear open field. Do not operate near buildings, high voltage cable lines, or trees to ensure safety operation. Operate in safe area only, away from other people. RC models are prone to accidents, failures, and crashes due to a variety of reasons including, lack of maintenance, pilot error, and radio interference. Pilots are responsible for their actions and damage or injury occurring during the
- Do not operate in inclement weather, such as rain, wind, snow and darkness.
- The product is composed of precision electrical components. It is critical to keep the product away from moisture and other contaminants. Do not allow them to get wet. Electrical damage may occur that could affect

- After each use, always allow the battery to cool down before recharging. When charging the battery pack, do not overcharge! If batteries get hot during charging, discontinue charging immediately and disconnect the battery from the charger. Never leave battery unattended while charging. If you are unsure of how to charge this battery, please seek the advice of experienced RC users. Never let children charge the battery without adult supervision
- Always turn on the transmitter before connecting the battery on the model. When turning off the model, always disconnect the battery first, and then turn off the transmitter. If the order is reversed, the model may become uncontrollable and cause serious damage.
- strongly recommend that you seek assistance from experienced RC users or join your local model flying club to gain the required knowledge and skill. As the manufacturer and distributor, we assume no liability for the use of this product.
- Before turning on your model and transmitter, please check to make sure no one else is operating under the same frequency. Frequency interference can cause your model, or other's models to crash. The guidance provided by experienced RC users will be valuable for the assembly, tuning.
- trimming, and actual first flight. • Never allow batteries to run low or you might lose control of
- the model. You should complete a successful pre-flight check of your radio equipment and model prior to each flight.
- Plastic is very susceptible to damage or deformation due to extreme heat and cold climate. Do not store the model near any source of heat such as oven or heater. Store the model

indoors, in a climate-controlled, room temperature



MADE IN CHINA