



# OI-7010 Modbus Register Map

Register Address (Hexadecimal)	Register Address (Decimal)	Data Description	R/W	Length	Units	Valid Response
<b>Radio Data</b>						
1	1	Channel 1 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
2	2	Channel 2 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
3	3	Channel 3 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
4	4	Channel 4 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
5	5	Channel 5 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
6	6	Channel 6 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
7	7	Channel 7 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
8	8	Channel 8 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
9	9	Channel 9 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
A	10	Channel 10 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
B	11	Channel 11 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
C	12	Channel 12 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
D	13	Channel 13 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
E	14	Channel 14 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
F	15	Channel 15 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
10	16	Channel 16 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
11	17	Channel 17 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
12	18	Channel 18 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
13	19	Channel 19 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
14	20	Channel 20 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
15	21	Channel 21 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
16	22	Channel 22 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
17	23	Channel 23 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
18	24	Channel 24 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
19	25	Channel 25 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
1A	26	Channel 26 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
1B	27	Channel 27 Radio Address	R/W	1	INTEGER	Radio Address (1-255)

Sheet1

1C	28	Channel 28 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
1D	29	Channel 29 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
1E	30	Channel 30 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
1F	31	Channel 31 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
20	32	Channel 32 Radio Address	R/W	1	INTEGER	Radio Address (1-255)
21	33	Channel 1 Reading	R	2	FLOAT	Any valid sensor reading
23	35	Channel 2 Reading	R	2	FLOAT	Any valid sensor reading
25	37	Channel 3 Reading	R	2	FLOAT	Any valid sensor reading
27	39	Channel 4 Reading	R	2	FLOAT	Any valid sensor reading
29	41	Channel 5 Reading	R	2	FLOAT	Any valid sensor reading
2B	43	Channel 6 Reading	R	2	FLOAT	Any valid sensor reading
2D	45	Channel 7 Reading	R	2	FLOAT	Any valid sensor reading
2F	47	Channel 8 Reading	R	2	FLOAT	Any valid sensor reading
31	49	Channel 9 Reading	R	2	FLOAT	Any valid sensor reading
33	51	Channel 10 Reading	R	2	FLOAT	Any valid sensor reading
35	53	Channel 11 Reading	R	2	FLOAT	Any valid sensor reading
37	55	Channel 12 Reading	R	2	FLOAT	Any valid sensor reading
39	57	Channel 13 Reading	R	2	FLOAT	Any valid sensor reading
3B	59	Channel 14 Reading	R	2	FLOAT	Any valid sensor reading
3D	61	Channel 15 Reading	R	2	FLOAT	Any valid sensor reading
3F	63	Channel 16 Reading	R	2	FLOAT	Any valid sensor reading
41	65	Channel 17 Reading	R	2	FLOAT	Any valid sensor reading
43	67	Channel 18 Reading	R	2	FLOAT	Any valid sensor reading
45	69	Channel 19 Reading	R	2	FLOAT	Any valid sensor reading
47	71	Channel 20 Reading	R	2	FLOAT	Any valid sensor reading
49	73	Channel 21 Reading	R	2	FLOAT	Any valid sensor reading
4B	75	Channel 22 Reading	R	2	FLOAT	Any valid sensor reading
4D	77	Channel 23 Reading	R	2	FLOAT	Any valid sensor reading
4F	79	Channel 24 Reading	R	2	FLOAT	Any valid sensor reading
51	81	Channel 25 Reading	R	2	FLOAT	Any valid sensor reading
53	83	Channel 26 Reading	R	2	FLOAT	Any valid sensor reading
55	85	Channel 27 Reading	R	2	FLOAT	Any valid sensor reading
57	87	Channel 28 Reading	R	2	FLOAT	Any valid sensor reading
59	89	Channel 29 Reading	R	2	FLOAT	Any valid sensor reading
5B	91	Channel 30 Reading	R	2	FLOAT	Any valid sensor reading
5D	93	Channel 31 Reading	R	2	FLOAT	Any valid sensor reading
5F	95	Channel 32 Reading	R	2	FLOAT	Any valid sensor reading
61	97	Channel 1 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below

62	98	Channel 2 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
63	99	Channel 3 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
64	100	Channel 4 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
65	101	Channel 5 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
66	102	Channel 6 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
67	103	Channel 7 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
68	104	Channel 8 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
69	105	Channel 9 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
6A	106	Channel 10 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
6B	107	Channel 11 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
6C	108	Channel 12 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
6D	109	Channel 13 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
6E	110	Channel 14 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
6F	111	Channel 15 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
70	112	Channel 16 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
71	113	Channel 17 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
72	114	Channel 18 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
73	115	Channel 19 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
74	116	Channel 20 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
75	117	Channel 21 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
76	118	Channel 22 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
77	119	Channel 23 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
78	120	Channel 24 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
79	121	Channel 25 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
7A	122	Channel 26 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
7B	123	Channel 27 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
7C	124	Channel 28 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
7D	125	Channel 29 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
7E	126	Channel 30 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
7F	127	Channel 31 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
80	128	Channel 32 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
81	129	Channel 1 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
83	131	Channel 2 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
85	133	Channel 3 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
87	135	Channel 4 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
89	137	Channel 5 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
8B	139	Channel 6 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
8D	141	Channel 7 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)

Sheet1

8F	143	Channel 8 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
91	145	Channel 9 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
93	147	Channel 10 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
95	149	Channel 11 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
97	151	Channel 12 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
99	153	Channel 13 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
9B	155	Channel 14 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
9D	157	Channel 15 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
9F	159	Channel 16 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
A1	161	Channel 17 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
A3	163	Channel 18 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
A5	165	Channel 19 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
A7	167	Channel 20 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
A9	169	Channel 21 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
AB	171	Channel 22 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
AD	173	Channel 23 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
AF	175	Channel 24 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
B1	177	Channel 25 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
B3	179	Channel 26 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
B5	181	Channel 27 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
B7	183	Channel 28 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
B9	185	Channel 29 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
BB	187	Channel 30 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
BD	189	Channel 31 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
BF	191	Channel 32 Battery	R	2	FLOAT	Sensor Input Voltage( >= 0.0)
C1	193	Channel 1 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
C2	194	Channel 2 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
C3	195	Channel 3 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
C4	196	Channel 4 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
C5	197	Channel 5 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
C6	198	Channel 6 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
C7	199	Channel 7 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
C8	200	Channel 8 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
C9	201	Channel 9 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
CA	202	Channel 10 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
CB	203	Channel 11 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
CC	204	Channel 12 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
CD	205	Channel 13 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout

CE	206	Channel 14 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
CF	207	Channel 15 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
D0	208	Channel 16 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
D1	209	Channel 17 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
D2	210	Channel 18 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
D3	211	Channel 19 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
D4	212	Channel 20 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
D5	213	Channel 21 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
D6	214	Channel 22 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
D7	215	Channel 23 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
D8	216	Channel 24 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
D9	217	Channel 25 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
DA	218	Channel 26 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
DB	219	Channel 27 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
DC	220	Channel 28 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
DD	221	Channel 29 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
DE	222	Channel 30 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
DF	223	Channel 31 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
E0	224	Channel 32 Sec Since Last Message	R	1	INTEGER	-1-32768 Seconds, -1 = no transmissions. Staying 0 = timeout
E1	225	Channel 1 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
E2	226	Channel 2 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
E3	227	Channel 3 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
E4	228	Channel 4 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
E5	229	Channel 5 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
E6	230	Channel 6 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
E7	231	Channel 7 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
E8	232	Channel 8 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
E9	233	Channel 9 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
EA	234	Channel 10 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
EB	235	Channel 11 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
EC	236	Channel 12 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
ED	237	Channel 13 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
EE	238	Channel 14 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
EF	239	Channel 15 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
F0	240	Channel 16 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
F1	241	Channel 17 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
F2	242	Channel 18 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
F3	243	Channel 19 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below

F4	244	Channel 20 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
F5	245	Channel 21 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
F6	246	Channel 22 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
F7	247	Channel 23 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
F8	248	Channel 24 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
F9	249	Channel 25 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
FA	250	Channel 26 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
FB	251	Channel 27 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
FC	252	Channel 28 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
FD	253	Channel 29 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
FE	254	Channel 30 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
FF	255	Channel 31 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
100	256	Channel 32 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
101	257	Channel 1 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
102	258	Channel 2 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
103	259	Channel 3 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
104	260	Channel 4 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
105	261	Channel 5 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
106	262	Channel 6 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
107	263	Channel 7 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
108	264	Channel 8 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
109	265	Channel 9 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
10A	266	Channel 10 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
10B	267	Channel 11 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
10C	268	Channel 12 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
10D	269	Channel 13 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
10E	270	Channel 14 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
10F	271	Channel 15 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
110	272	Channel 16 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
111	273	Channel 17 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
112	274	Channel 18 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
113	275	Channel 19 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
114	276	Channel 20 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
115	277	Channel 21 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
116	278	Channel 22 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
117	279	Channel 23 Gas type	R	1	ENUMERATION	0-127 See Gas Enumeration below
118	280	Channel 24 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
119	281	Channel 25 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below

11A	282	Channel 26 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
11B	283	Channel 27 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
11C	284	Channel 28 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
11D	285	Channel 29 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
11E	286	Channel 30 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
11F	287	Channel 31 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
120	288	Channel 32 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
121	289	Channel 1 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
122	290	Channel 2 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
123	291	Channel 3 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
124	292	Channel 4 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
125	293	Channel 5 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
126	294	Channel 6 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
127	295	Channel 7 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
128	296	Channel 8 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
129	297	Channel 9 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
12A	298	Channel 10 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
12B	299	Channel 11 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
12C	300	Channel 12 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
12D	301	Channel 13 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
12E	302	Channel 14 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
12F	303	Channel 15 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
130	304	Channel 16 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
131	305	Channel 17 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
132	306	Channel 18 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
133	307	Channel 19 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
134	308	Channel 20 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
135	309	Channel 21 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
136	310	Channel 22 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
137	311	Channel 23 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
138	312	Channel 24 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
139	313	Channel 25 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
13A	314	Channel 26 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
13B	315	Channel 27 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
13C	316	Channel 28 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
13D	317	Channel 29 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
13E	318	Channel 30 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
13F	319	Channel 31 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below

Sheet1

140	320	Channel 32 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
141	321	Channel 1 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
142	322	Channel 2 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
143	323	Channel 3 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
144	324	Channel 4 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
145	325	Channel 5 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
146	326	Channel 6 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
147	327	Channel 7 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
148	328	Channel 8 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
149	329	Channel 9 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
14A	330	Channel 10 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
14B	331	Channel 11 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
14C	332	Channel 12 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
14D	333	Channel 13 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
14E	334	Channel 14 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
14F	335	Channel 15 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
150	336	Channel 16 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
151	337	Channel 17 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
152	338	Channel 18 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
153	339	Channel 19 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
154	340	Channel 20 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
155	341	Channel 21 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
156	342	Channel 22 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
157	343	Channel 23 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
158	344	Channel 24 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
159	345	Channel 25 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
15A	346	Channel 26 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
15B	347	Channel 27 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
15C	348	Channel 28 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
15D	349	Channel 29 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
15E	350	Channel 30 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
15F	351	Channel 31 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
160	352	Channel 32 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
161	353	Channel 1 Relay 1 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
162	354	Channel 2 Relay 1 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
163	355	Channel 3 Relay 1 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
164	356	Channel 4 Relay 1 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
165	357	Channel 5 Relay 1 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on



Sheet1

166	358	Channel 6 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
167	359	Channel 7 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
168	360	Channel 8 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
169	361	Channel 9 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
16A	362	Channel 10 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
16B	363	Channel 11 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
16C	364	Channel 12 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
16D	365	Channel 13 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
16E	366	Channel 14 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
16F	367	Channel 15 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
170	368	Channel 16 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
171	369	Channel 17 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
172	370	Channel 18 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
173	371	Channel 19 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
174	372	Channel 20 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
175	373	Channel 21 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
176	374	Channel 22 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
177	375	Channel 23 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
178	376	Channel 24 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
179	377	Channel 25 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
17A	378	Channel 26 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
17B	379	Channel 27 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
17C	380	Channel 28 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
17D	381	Channel 29 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
17E	382	Channel 30 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
17F	383	Channel 31 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
180	384	Channel 32 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
181	385	Channel 1 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
182	386	Channel 2 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
183	387	Channel 3 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
184	388	Channel 4 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
185	389	Channel 5 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
186	390	Channel 6 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
187	391	Channel 7 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
188	392	Channel 8 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
189	393	Channel 9 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
18A	394	Channel 10 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
18B	395	Channel 11 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high

Sheet1

18C	396	Channel 12 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
18D	397	Channel 13 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
18E	398	Channel 14 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
18F	399	Channel 15 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
190	400	Channel 16 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
191	401	Channel 17 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
192	402	Channel 18 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
193	403	Channel 19 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
194	404	Channel 20 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
195	405	Channel 21 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
196	406	Channel 22 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
197	407	Channel 23 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
198	408	Channel 24 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
199	409	Channel 25 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
19A	410	Channel 26 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
19B	411	Channel 27 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
19C	412	Channel 28 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
19D	413	Channel 29 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
19E	414	Channel 30 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
19F	415	Channel 31 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
1A0	416	Channel 32 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
1A1	417	Channel 1 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1A3	419	Channel 2 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1A5	421	Channel 3 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1A7	423	Channel 4 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1A9	425	Channel 5 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1AB	427	Channel 6 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1AD	429	Channel 7 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1AF	431	Channel 8 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1B1	433	Channel 9 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1B3	435	Channel 10 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1B5	437	Channel 11 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1B7	439	Channel 12 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1B9	441	Channel 13 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1BB	443	Channel 14 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1BD	445	Channel 15 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1BF	447	Channel 16 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1C1	449	Channel 17 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0

Sheet1

1C3	451	Channel 18 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1C5	453	Channel 19 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1C7	455	Channel 20 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1C9	457	Channel 21 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1CB	459	Channel 22 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1CD	461	Channel 23 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1CF	463	Channel 24 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1D1	465	Channel 25 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1D3	467	Channel 26 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1D5	469	Channel 27 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1D7	471	Channel 28 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1D9	473	Channel 29 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1DB	475	Channel 30 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1DD	477	Channel 31 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1DF	479	Channel 32 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1E1	481	Channel 1 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1E2	482	Channel 2 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1E3	483	Channel 3 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1E4	484	Channel 4 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1E5	485	Channel 5 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1E6	486	Channel 6 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1E7	487	Channel 7 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1E8	488	Channel 8 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1E9	489	Channel 9 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1EA	490	Channel 10 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1EB	491	Channel 11 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1EC	492	Channel 12 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1ED	493	Channel 13 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1EE	494	Channel 14 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1EF	495	Channel 15 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1F0	496	Channel 16 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1F1	497	Channel 17 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1F2	498	Channel 18 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1F3	499	Channel 19 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1F4	500	Channel 20 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1F5	501	Channel 21 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1F6	502	Channel 22 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1F7	503	Channel 23 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch

1F8	504	Channel 24 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1F9	505	Channel 25 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1FA	506	Channel 26 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1FB	507	Channel 27 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1FC	508	Channel 28 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1FD	509	Channel 29 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1FE	510	Channel 30 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1FF	511	Channel 31 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
200	512	Channel 32 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
201	513	Channel 1 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
202	514	Channel 2 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
203	515	Channel 3 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
204	516	Channel 4 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
205	517	Channel 5 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
206	518	Channel 6 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
207	519	Channel 7 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
208	520	Channel 8 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
209	521	Channel 9 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
20A	522	Channel 10 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
20B	523	Channel 11 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
20C	524	Channel 12 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
20D	525	Channel 13 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
20E	526	Channel 14 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
20F	527	Channel 15 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
210	528	Channel 16 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
211	529	Channel 17 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
212	530	Channel 18 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
213	531	Channel 19 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
214	532	Channel 20 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
215	533	Channel 21 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
216	534	Channel 22 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
217	535	Channel 23 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
218	536	Channel 24 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
219	537	Channel 25 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
21A	538	Channel 26 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
21B	539	Channel 27 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
21C	540	Channel 28 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
21D	541	Channel 29 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on

Sheet1

21E	542	Channel 30 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
21F	543	Channel 31 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
220	544	Channel 32 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
221	545	Channel 1 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
222	546	Channel 2 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
223	547	Channel 3 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
224	548	Channel 4 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
225	549	Channel 5 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
226	550	Channel 6 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
227	551	Channel 7 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
228	552	Channel 8 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
229	553	Channel 9 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
22A	554	Channel 10 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
22B	555	Channel 11 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
22C	556	Channel 12 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
22D	557	Channel 13 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
22E	558	Channel 14 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
22F	559	Channel 15 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
230	560	Channel 16 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
231	561	Channel 17 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
232	562	Channel 18 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
233	563	Channel 19 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
234	564	Channel 20 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
235	565	Channel 21 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
236	566	Channel 22 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
237	567	Channel 23 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
238	568	Channel 24 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
239	569	Channel 25 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
23A	570	Channel 26 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
23B	571	Channel 27 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
23C	572	Channel 28 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
23D	573	Channel 29 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
23E	574	Channel 30 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
23F	575	Channel 31 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
240	576	Channel 32 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
241	577	Channel 1 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
243	579	Channel 2 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
245	581	Channel 3 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0

Sheet1

247	583	Channel 4 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
249	585	Channel 5 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
24B	587	Channel 6 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
24D	589	Channel 7 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
24F	591	Channel 8 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
251	593	Channel 9 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
253	595	Channel 10 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
255	597	Channel 11 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
257	599	Channel 12 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
259	601	Channel 13 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
25B	603	Channel 14 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
25D	605	Channel 15 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
25F	607	Channel 16 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
261	609	Channel 17 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
263	611	Channel 18 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
265	613	Channel 19 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
267	615	Channel 20 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
269	617	Channel 21 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
26B	619	Channel 22 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
26D	621	Channel 23 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
26F	623	Channel 24 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
271	625	Channel 25 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
273	627	Channel 26 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
275	629	Channel 27 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
277	631	Channel 28 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
279	633	Channel 29 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
27B	635	Channel 30 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
27D	637	Channel 31 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
27F	639	Channel 32 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
281	641	Channel 1 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
282	642	Channel 2 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
283	643	Channel 3 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
284	644	Channel 4 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
285	645	Channel 5 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
286	646	Channel 6 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
287	647	Channel 7 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
288	648	Channel 8 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
289	649	Channel 9 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch

28A	650	Channel 10 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
28B	651	Channel 11 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
28C	652	Channel 12 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
28D	653	Channel 13 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
28E	654	Channel 14 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
28F	655	Channel 15 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
290	656	Channel 16 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
291	657	Channel 17 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
292	658	Channel 18 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
293	659	Channel 19 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
294	660	Channel 20 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
295	661	Channel 21 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
296	662	Channel 22 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
297	663	Channel 23 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
298	664	Channel 24 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
299	665	Channel 25 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
29A	666	Channel 26 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
29B	667	Channel 27 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
29C	668	Channel 28 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
29D	669	Channel 29 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
29E	670	Channel 30 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
29F	671	Channel 31 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
2A0	672	Channel 32 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
2A1	673	Channel 1 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2A2	674	Channel 2 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2A3	675	Channel 3 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2A4	676	Channel 4 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2A5	677	Channel 5 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2A6	678	Channel 6 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2A7	679	Channel 7 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2A8	680	Channel 8 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2A9	681	Channel 9 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2AA	682	Channel 10 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2AB	683	Channel 11 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2AC	684	Channel 12 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2AD	685	Channel 13 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2AE	686	Channel 14 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2AF	687	Channel 15 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on

2B0	688	Channel 16 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2B1	689	Channel 17 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2B2	690	Channel 18 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2B3	691	Channel 19 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2B4	692	Channel 20 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2B5	693	Channel 21 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2B6	694	Channel 22 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2B7	695	Channel 23 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2B8	696	Channel 24 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2B9	697	Channel 25 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2BA	698	Channel 26 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2BB	699	Channel 27 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2BC	700	Channel 28 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2BD	701	Channel 29 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2BE	702	Channel 30 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2BF	703	Channel 31 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2C0	704	Channel 32 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2C1	705	Channel 1 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2C2	706	Channel 2 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2C3	707	Channel 3 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2C4	708	Channel 4 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2C5	709	Channel 5 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2C6	710	Channel 6 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2C7	711	Channel 7 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2C8	712	Channel 8 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2C9	713	Channel 9 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2CA	714	Channel 10 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2CB	715	Channel 11 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2CC	716	Channel 12 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2CD	717	Channel 13 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2CE	718	Channel 14 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2CF	719	Channel 15 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2D0	720	Channel 16 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2D1	721	Channel 17 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2D2	722	Channel 18 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2D3	723	Channel 19 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2D4	724	Channel 20 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2D5	725	Channel 21 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high



Sheet1

2D6	726	Channel 22 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2D7	727	Channel 23 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2D8	728	Channel 24 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2D9	729	Channel 25 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2DA	730	Channel 26 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2DB	731	Channel 27 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2DC	732	Channel 28 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2DD	733	Channel 29 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2DE	734	Channel 30 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2DF	735	Channel 31 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2E0	736	Channel 32 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
2E1	737	Channel 1 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
2E3	739	Channel 2 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
2E5	741	Channel 3 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
2E7	743	Channel 4 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
2E9	745	Channel 5 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
2EB	747	Channel 6 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
2ED	749	Channel 7 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
2EF	751	Channel 8 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
2F1	753	Channel 9 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
2F3	755	Channel 10 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
2F5	757	Channel 11 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
2F7	759	Channel 12 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
2F9	761	Channel 13 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
2FB	763	Channel 14 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
2FD	765	Channel 15 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
2FF	767	Channel 16 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
301	769	Channel 17 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
303	771	Channel 18 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
305	773	Channel 19 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
307	775	Channel 20 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
309	777	Channel 21 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
30B	779	Channel 22 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
30D	781	Channel 23 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
30F	783	Channel 24 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
311	785	Channel 25 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
313	787	Channel 26 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
315	789	Channel 27 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0

Sheet1

317	791	Channel 28 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
319	793	Channel 29 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
31B	795	Channel 30 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
31D	797	Channel 31 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
31F	799	Channel 32 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
321	801	Channel 1 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
322	802	Channel 2 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
323	803	Channel 3 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
324	804	Channel 4 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
325	805	Channel 5 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
326	806	Channel 6 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
327	807	Channel 7 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
328	808	Channel 8 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
329	809	Channel 9 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
32A	810	Channel 10 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
32B	811	Channel 11 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
32C	812	Channel 12 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
32D	813	Channel 13 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
32E	814	Channel 14 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
32F	815	Channel 15 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
330	816	Channel 16 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
331	817	Channel 17 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
332	818	Channel 18 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
333	819	Channel 19 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
334	820	Channel 20 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
335	821	Channel 21 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
336	822	Channel 22 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
337	823	Channel 23 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
338	824	Channel 24 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
339	825	Channel 25 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
33A	826	Channel 26 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
33B	827	Channel 27 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
33C	828	Channel 28 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
33D	829	Channel 29 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
33E	830	Channel 30 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
33F	831	Channel 31 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
340	832	Channel 32 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
341	833	Channel 1 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on

Sheet1

342	834	Channel 2 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
343	835	Channel 3 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
344	836	Channel 4 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
345	837	Channel 5 Relay 4 On/4ff	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
346	838	Channel 6 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
347	839	Channel 7 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
348	840	Channel 8 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
349	841	Channel 9 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
34A	842	Channel 10 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
34B	843	Channel 11 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
34C	844	Channel 12 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
34D	845	Channel 13 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
34E	846	Channel 14 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
34F	847	Channel 15 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
350	848	Channel 16 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
351	849	Channel 17 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
352	850	Channel 18 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
353	851	Channel 19 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
354	852	Channel 20 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
355	853	Channel 21 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
356	854	Channel 22 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
357	855	Channel 23 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
358	856	Channel 24 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
359	857	Channel 25 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
35A	858	Channel 26 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
35B	859	Channel 27 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
35C	860	Channel 28 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
35D	861	Channel 29 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
35E	862	Channel 30 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
35F	863	Channel 31 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
360	864	Channel 32 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
361	865	Channel 1 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
362	866	Channel 2 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
363	867	Channel 3 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
364	868	Channel 4 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
365	869	Channel 5 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
366	870	Channel 6 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
367	871	Channel 7 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high

368	872	Channel 8 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
369	873	Channel 9 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
36A	874	Channel 10 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
36B	875	Channel 11 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
36C	876	Channel 12 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
36D	877	Channel 13 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
36E	878	Channel 14 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
36F	879	Channel 15 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
370	880	Channel 16 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
371	881	Channel 17 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
372	882	Channel 18 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
373	883	Channel 19 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
374	884	Channel 20 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
375	885	Channel 21 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
376	886	Channel 22 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
377	887	Channel 23 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
378	888	Channel 24 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
379	889	Channel 25 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
37A	890	Channel 26 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
37B	891	Channel 27 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
37C	892	Channel 28 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
37D	893	Channel 29 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
37E	894	Channel 30 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
37F	895	Channel 31 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
380	896	Channel 32 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
381	897	Channel 1 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
383	899	Channel 2 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
385	901	Channel 3 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
387	903	Channel 4 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
389	905	Channel 5 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
38B	907	Channel 6 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
38D	909	Channel 7 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
38F	911	Channel 8 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
391	913	Channel 9 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
393	915	Channel 10 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
395	917	Channel 11 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
397	919	Channel 12 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
399	921	Channel 13 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0

Sheet1

39B	923	Channel 14 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
39D	925	Channel 15 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
39F	927	Channel 16 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3A1	929	Channel 17 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3A3	931	Channel 18 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3A5	933	Channel 19 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3A7	935	Channel 20 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3A9	937	Channel 21 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3AB	939	Channel 22 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3AD	941	Channel 23 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3AF	943	Channel 24 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3B1	945	Channel 25 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3B3	947	Channel 26 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3B5	949	Channel 27 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3B7	951	Channel 28 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3B9	953	Channel 29 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3BB	955	Channel 30 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3BD	957	Channel 31 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3BF	959	Channel 32 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3C1	961	Channel 1 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3C2	962	Channel 2 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3C3	963	Channel 3 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3C4	964	Channel 4 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3C5	965	Channel 5 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3C6	966	Channel 6 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3C7	967	Channel 7 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3C8	968	Channel 8 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3C9	969	Channel 9 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3CA	970	Channel 10 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3CB	971	Channel 11 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3CC	972	Channel 12 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3CD	973	Channel 13 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3CE	974	Channel 14 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3CF	975	Channel 15 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3D0	976	Channel 16 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3D1	977	Channel 17 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3D2	978	Channel 18 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3D3	979	Channel 19 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch

3D4	980	Channel 20 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3D5	981	Channel 21 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3D6	982	Channel 22 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3D7	983	Channel 23 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3D8	984	Channel 24 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3D9	985	Channel 25 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3DA	986	Channel 26 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3DB	987	Channel 27 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3DC	988	Channel 28 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3DD	989	Channel 29 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3DE	990	Channel 30 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3DF	991	Channel 31 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3E0	992	Channel 32 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3E1	993	Channel 29 Select Wired or Radio	R/W	1	ENUMERATION	0 - 1 ,0 means wired, 1 means radio
3E2	994	Channel 30 Select Wired or Radio	R/W	1	ENUMERATION	0 - 1 ,0 means wired, 1 means radio
3E3	995	Channel 31 Select Wired or Radio	R/W	1	ENUMERATION	0 - 1 ,0 means wired, 1 means radio
3E4	996	Channel 32 Select Wired or Radio	R/W	1	ENUMERATION	0 - 1 ,0 means wired, 1 means radio
3E5	997	Channel 29 Scale	R/W	1	INTEGER	1—65000
3E6	998	Channel 30 Scale	R/W	1	INTEGER	1—65000
3E7	999	Channel 31 Scale	R/W	1	INTEGER	1—65000
3E8	1000	Channel 32 Scale	R/W	1	INTEGER	1—65000
<b>Modbus and Build Data</b>						
1771	6001	Modbus Address	R/W	1	INTEGER	1 - 247
1772	6002	Modbus Baud Rate	R/W	1	INTEGER	Any Valid Baud Rate. See Below.
1773	6003	Month	R	1	INTEGER	1 - 12
1774	6004	Day	R	1	INTEGER	1 - 31
1775	6005	Year	R	1	INTEGER	2009 -
1776	6006	Serial Number Character	R	1	ENUMERATION	0 - 26 See Serial Number below
1777	6007	Serial Number	R	2	LONG INT	1 - 99999
<b>Settings in Startup Menu</b>						
177A	6010	Can Change Startup Menu Options	R	1	ENUMERATION	0 - 1, 1 can change startup menu items. 0 cannot change.
177B	6011	Restore to Factory Default	R/W	1	ENUMERATION	When read will be 0. When you want to restore write a 1.
177C	6012	Relay 4 as Fault Relay	R/W	1	ENUMERATION	0 - 1, 0 means normal relay, 1 means Fault Relay
177D	6013	Relay 1 Fail Safe	R/W	1	ENUMERATION	0 - 1, 0 means not Fail Safe, 1 means Fail Safe
177E	6014	Relay 2 Fail Safe	R/W	1	ENUMERATION	0 - 1, 0 means not Fail Safe, 1 means Fail Safe
177F	6015	Relay 3 Fail Safe	R/W	1	ENUMERATION	0 - 1, 0 means not Fail Safe, 1 means Fail Safe
1780	6016	Relay 4 Fail Safe	R/W	1	ENUMERATION	0 - 1, 0 means not Fail Safe, 1 means Fail Safe
1781	6017	Fault Terminal Fail Safe	R/W	1	ENUMERATION	0 - 1, 0 means not Fail Safe, 1 means Fail Safe

1782	6018	Radio Timeout	R/W	1	INTEGER	6-255. This is the timeout in minutes.
1783	6019	Network Channel	R/W	1	INTEGER	1—78
1784	6020	Primary Secondary	R/W	1	ENUMERATION	0 – 1, 0 means Primary, 1 means Secondary.
<b>Relays in Alarm State</b>						
1785	6021	Relay 1 is in Alarm	R	1	ENUMERATION	0 – 1, 0 means not in Alarm, 1 means in Alarm
1786	6022	Relay 2 is in Alarm	R	1	ENUMERATION	0 – 1, 0 means not in Alarm, 1 means in Alarm
1787	6023	Relay 3 is in Alarm	R	1	ENUMERATION	0 – 1, 0 means not in Alarm, 1 means in Alarm
1788	6024	Relay 4 is in Alarm	R	1	ENUMERATION	0 – 1, 0 means not in Alarm, 1 means in Alarm
1789	6025	Fault Relay is in Alarm	R	1	ENUMERATION	0 – 1, 0 means not in Alarm, 1 means in Alarm
178A	6026	Channels 1-32 in Alarm	R	2	ENUMERATION	Each bit corresponds to a Channel. 1 means in Alarm
178C	6028	Not used on 32 Channel 7010		2		
178E	6030	Reset Relays	R/W	1	ENUMERATION	Reads always a 0. Write 1 to reset the relays.
178F	6031	Channels in Fault	R	1	ENUMERATION	0 – 3, 0 no fault, 1 fault 1-16, 2 fault 17-32, 3 fault on both
1790	6032	Not used on 32 Channel 7010				
1791	6033	Fault: There is another Primary Monitor	R	1	ENUMERATION	0-1, 0 means no fault, 1 means there is another Primary
<b>Diagnostics Data</b>						
2704	9988	Reset	R/W	1	INTEGER	Read 0. If user sets to 1, resets the unit.
2705	9989	Serial Receive Good Count	R	1	UINT	0 – 65535
2706	9990	Serial Receive Error Count	R	1	UINT	0 – 65535
2707	9991	Serial Transmit Good Count	R	1	UINT	0 – 65535
2708	9992	Serial Transmit Error Count	R	1	UINT	0 – 65535
2709	9993	Radio Receive Good Count	R	1	UINT	0 – 65535
270A	9994	Radio Receive Error Count	R	1	UINT	0 – 65535
270B	9995	Radio Transmit Good Count	R	1	UINT	0 – 65535
270C	9996	Radio Transmit Error Count	R	1	UINT	0 – 65535
270D	9997	Uptime Days	R	1	UINT	0 – 65535
270E	9998	Uptime Hours	R	1	UINT	0 – 65535
270F	9999	Uptime Minutes	R	1	UINT	0 – 65535

MODE SENSOR	MODE
0	NORMAL
1	NULL
2	CALIBRATION
3	RELAY
4	Radio ADD
5	Diagnostic/ Batt

Valid Baud Rates
4800
9600
19200

	Advanced
6	Menu
7	Admin Menu

GAS TYPE NUM	GAS
0	H2S
1	SO2
2	O2
3	CO
4	CL2
5	CO2
6	LEL
7	VOC
8	Ft. for tank
9	HCl
10	NH3
11	H2
12	ClO2
13	F2
14	HCN
15	HF
16..N	Future Gases

Sensor TYPE NUM	SENSOR
0	EC
1	IR
2	CB
3	MOS
4	PID
5..N	Future Sensors

FAULT	FAULT
0	NONE
1	Sensor Timeout
2	Future Error
3	Future Error
4	ADC not responding
5	Future Error
6	Future Error
7	Future Error



8	Two Sensors Same Add
9	Sensor Radio Timeout
10	When Sensor is wired, it means no sensor is connected
11...12	Future Error
13	Unspecified Error on sensor unit. Shown only on Monitor
14	No Primary Monitor at Sensor Head
15	Monitor Fault

Serial Number Char	Char
1	A
2	B
3	C
4	D
5	E
6	F
7	G
8	H
9	I
10	J
11	K
12	L
13	M
14	N
15	O
16	P
17	Q
18	R
19	S
20	T
21	U

Sheet1

22	V
23	W
24	X
25	Y
26	Z