

## Flat-Surface, Self-Cleaning **pH and ORP Electrodes**



**Specifications** Range

0-14pH (0-12pH without Na+ error)

+/- 2000mV for ORP

**Wetted Materials** 

Body/Junction: CPVC/HDPE ("-CD" models)

PVDF/ Porous PVDF ("-KD" models)

Measuring Surface: pH glass (pH), Platinum or Gold (ORP)

**Temperature/Pressure Range** 0C\* - 75C (0-100psig), 0C\*-80C (0-85psig)

Note: From 0 to 10C, electrodes will exhibit slower response time.

**Reference Type** Ag/AgCl, Sealed Double Junction

Specifications for Fitting FC66P (also included in FC66TC, FC67P, FC67TC,

FC68P and FC68TC)

Material 20% glass-filled polypropylene, gray color

Specifications for Cables (S653, S648 and also included in FC66TC, FC67TC

and FC68TC)

**Cable Type** RG174 Coaxial cable with noise reduction layer (S653, S648), approx OD = .120

Material Cap = CPVC, cable jacket = PVC

FC66TC, FC67TC, FC68TC = RG174 coaxial **Cable Type** 

> cable x 1, 3 each PVC jacketed 20AWG wires, Red, blk, grn with Outer PVC jacket

Parts covered by this product data sheet include:

S660CD, S660CD-ORP, S661CD, S661CD-ORP, S662CD (also -LC, -HF versions), FC66P, FC66TC, FC67P, FC67TC, FC68P, FC68TC, S648, S653

#### Quick disconnect design saves time and money

Installs in seconds, no tools necessary

Flat-surface design resists coating

**Available with or without ATC elements** 


In-line mountings are ideal for replacing existing threaded electrodes. They are useful in piping systems where flow can be shut off for electrode maintenance and where flow rates match the application's needs; for example, turbulent flow is needed in self-cleaning applications. A simple, reusable gland is used to mount the electrode. Electrodes, glands and flow cells are available to fit 3/4", 1" and 2" lines. Mounting hardware is available with or without ATC elements. Choose from standard electrode models with HT gels, low ionic models and HF resistant models.






#### Flat-surface, Self-cleaning pH and ORP Electrodes

### CPVC pH AND ORP ELECTRODES FOR IN-LINE INSTALLATION




MODEL NO.	DIM. A	DIM. B	DIM. C
S660CD	2.50"	4.25"	0.75"
S661CD	3.50"	5.25"	0.75"
S662CD	4.25"	5.90"	0.75"


### FC66P GLAND AND NUT FITTING FOR IN-LINE INSTALLATION



## S653 CABLE ASSEMBLY FOR CONDUIT USE WITH IN-LINE ELECTRODES WITHOUT ATC




# S648 CABLE ASSEMBLY FOR EXPOSED USE WITH IN-LINE ELECTRODES WITHOUT ATC






### Flat-surface, Self-cleaning pH and ORP Electrodes

### INSTALLATION DRAWING OF S660CD IN 3/4" TEE



### INSTALLATION DRAWING OF S661CD OR S662CD IN 1" OR 2"TEE



MODEL NO.	DIMENSION A	DIMENSION B	DIMENSION C
FC67P/TC	3.50"	6.25"	3/4" x 1" REDUCER
FC68P/TC	4.70"	7.80"	3/4" x 2" REDUCER



#### **ORDERING INFORMATION**


Systems without temperature compensation

ORDER 3 ITEMS	DESCRIPTION	CPVC PARTS	KYNAR (PVDF) PARTS
Select one flow cell and gland or gland only	Flow cell and gland Gland only(1" and 2" include reducing bushing)	FC66C(3/4"), FC67C(1"), FC68C(2") FC66P, FC67PFC68P	N/A
	3	S660CD (3/4"), S661CD (1"),	
2. Select one electrode	Combination pH electrode	S662CD (2") Or Same models with -LC for low	N/A
		ionic samples or -HF for samples containing acidic flourides.	N/A
	ORP combination electrode	S660CD-ORP(3/4"), S661CD- ORP(1") S662CD-ORP(2")	
3. Select one cable assembly	For conduit use	S653-"cable length"-"connector"	S653K-"cable length"-"connector"


Systems with temperature compensation

	•		
ORDER 2 ITEMS	DESCRIPTION	CPVC PARTS	KYNAR (PVDF) PARTS
1. Select one flow cell	Flow cell, cable assembly with ATC	FC66TC-"ATC CODE"-cable length-connectors (3/4")	N/A
		FC67TC-"ATC CODE"-cable length- connectors (1")	и и
		FC68TC-"ATC CODE"-cable length- connectors (2")	ии
2. Select one electrode	Combination pH electrode	S660CD (3/4"), S661CD(1"), S662CD(2")	N/A
	ORP combination electrode	S660CD-ORP(3/4"), S661CD-ORP(1")	и и
		S662CD-ORP(2")	ии


#### **SELF-CLEANING OPERATION**



#### **ABRASION-FREE OPERATION**



#### **VISCOUS MATERIAL OPERATION**





11751 Markon Dr. Garden Grove, CA 92841 USA Tel: 714-895-4344 Fax: 714-894-4839 E-mail: info@sensorex.com www.sensorex.com