

◀◀◀ **WARNING: READ THIS BEFORE USING PRODUCT!** ▶▶▶

QUICK START GUIDE

[**ACT-IR100UD-MDT GENERAL SETUP PROCEDURE**]

1. Make sure USB dongle is **NOT** plugged into PC until you have installed the driver.
2. From “**Add or Remove Program**” for Win2K/XP (or from “**Programs and Features**” for Windows Vista/Win 7), make sure there is no driver named: “**PL-2303 USB-to-Serial**” or “**PL-2303 Vista Driver Installer**” exists in PC. If exists, please **remove it first**.
3. Insert the installation CD and it will install FILE RECEIVE and COMSET Configuration Utilities & Driver into PC automatically. If you find it not AUTORUN, especially in Vista/Win 7, make sure the “**AUTORUN**” option under “**Control Panel=> AUTOPLAY**” has been selected. And also, disable **UAC (User Access Control)** from Win Vista/7/8. But for **Windows 8**, please select **Okey.bat** and right click it to show shortcut Window and select “**Run as administrator**” to unlock the UAC first. Then restart PC to take change effective. Then please browse the CD and run **Auto.bat** manually.
4. A welcome screen for Utilities installer will show up. At the end of the Utilities installation, Driver installation will be continued then.
5. When this Installation completes, click “**Finish**” to close the Wizard window. For Windows 8, please Restart PC to resume back UAC.
6. Now plug ACT-IR100UD-MDT adapter into USB port. It will lead you to a “**Found New Hardware**” procedure to complete the installation
7. For details of the procedure, please refer to Chapters of **Installation** in the manual.