



OI-7010 Modbus Register Map

Register Address (Hexadecimal)	Register Address (Decimal)	Data Description	R/W	Length	Units	Valid Response
Radio Data						
1	1	Channel 1 Radio Address	R	1	INTEGER	Radio Address (1-1000)
2	2	Channel 2 Radio Address	R	1	INTEGER	Radio Address (1-1000)
3	3	Channel 3 Radio Address	R	1	INTEGER	Radio Address (1-1000)
4	4	Channel 4 Radio Address	R	1	INTEGER	Radio Address (1-1000)
5	5	Channel 5 Radio Address	R	1	INTEGER	Radio Address (1-1000)
6	6	Channel 6 Radio Address	R	1	INTEGER	Radio Address (1-1000)
7	7	Channel 7 Radio Address	R	1	INTEGER	Radio Address (1-1000)
8	8	Channel 8 Radio Address	R	1	INTEGER	Radio Address (1-1000)
9	9	Channel 9 Radio Address	R	1	INTEGER	Radio Address (1-1000)
A	10	Channel 10 Radio Address	R	1	INTEGER	Radio Address (1-1000)
B	11	Channel 11 Radio Address	R	1	INTEGER	Radio Address (1-1000)
C	12	Channel 12 Radio Address	R	1	INTEGER	Radio Address (1-1000)
D	13	Channel 13 Radio Address	R	1	INTEGER	Radio Address (1-1000)
E	14	Channel 14 Radio Address	R	1	INTEGER	Radio Address (1-1000)
F	15	Channel 15 Radio Address	R	1	INTEGER	Radio Address (1-1000)
10	16	Channel 16 Radio Address	R	1	INTEGER	Radio Address (1-1000)
11	17	Channel 17 Radio Address	R	1	INTEGER	Radio Address (1-1000)
12	18	Channel 18 Radio Address	R	1	INTEGER	Radio Address (1-1000)
13	19	Channel 19 Radio Address	R	1	INTEGER	Radio Address (1-1000)
14	20	Channel 20 Radio Address	R	1	INTEGER	Radio Address (1-1000)
15	21	Channel 21 Radio Address	R	1	INTEGER	Radio Address (1-1000)
16	22	Channel 22 Radio Address	R	1	INTEGER	Radio Address (1-1000)
17	23	Channel 23 Radio Address	R	1	INTEGER	Radio Address (1-1000)
18	24	Channel 24 Radio Address	R	1	INTEGER	Radio Address (1-1000)
19	25	Channel 25 Radio Address	R	1	INTEGER	Radio Address (1-1000)
1A	26	Channel 26 Radio Address	R	1	INTEGER	Radio Address (1-1000)
1B	27	Channel 27 Radio Address	R	1	INTEGER	Radio Address (1-1000)
1C	28	Channel 28 Radio Address	R	1	INTEGER	Radio Address (1-1000)
1D	29	Channel 29 Radio Address	R	1	INTEGER	Radio Address (1-1000)

Sheet1

1E	30	Channel 30 Radio Address	R	1	INTEGER	Radio Address (1-1000)
1F	31	Channel 31 Radio Address	R	1	INTEGER	Radio Address (1-1000)
20	32	Channel 32 Radio Address	R	1	INTEGER	Radio Address (1-1000)
21	33	Channel 1 Reading	R	2	FLOAT	Any valid sensor reading
23	35	Channel 2 Reading	R	2	FLOAT	Any valid sensor reading
25	37	Channel 3 Reading	R	2	FLOAT	Any valid sensor reading
27	39	Channel 4 Reading	R	2	FLOAT	Any valid sensor reading
29	41	Channel 5 Reading	R	2	FLOAT	Any valid sensor reading
2B	43	Channel 6 Reading	R	2	FLOAT	Any valid sensor reading
2D	45	Channel 7 Reading	R	2	FLOAT	Any valid sensor reading
2F	47	Channel 8 Reading	R	2	FLOAT	Any valid sensor reading
31	49	Channel 9 Reading	R	2	FLOAT	Any valid sensor reading
33	51	Channel 10 Reading	R	2	FLOAT	Any valid sensor reading
35	53	Channel 11 Reading	R	2	FLOAT	Any valid sensor reading
37	55	Channel 12 Reading	R	2	FLOAT	Any valid sensor reading
39	57	Channel 13 Reading	R	2	FLOAT	Any valid sensor reading
3B	59	Channel 14 Reading	R	2	FLOAT	Any valid sensor reading
3D	61	Channel 15 Reading	R	2	FLOAT	Any valid sensor reading
3F	63	Channel 16 Reading	R	2	FLOAT	Any valid sensor reading
41	65	Channel 17 Reading	R	2	FLOAT	Any valid sensor reading
43	67	Channel 18 Reading	R	2	FLOAT	Any valid sensor reading
45	69	Channel 19 Reading	R	2	FLOAT	Any valid sensor reading
47	71	Channel 20 Reading	R	2	FLOAT	Any valid sensor reading
49	73	Channel 21 Reading	R	2	FLOAT	Any valid sensor reading
4B	75	Channel 22 Reading	R	2	FLOAT	Any valid sensor reading
4D	77	Channel 23 Reading	R	2	FLOAT	Any valid sensor reading
4F	79	Channel 24 Reading	R	2	FLOAT	Any valid sensor reading
51	81	Channel 25 Reading	R	2	FLOAT	Any valid sensor reading
53	83	Channel 26 Reading	R	2	FLOAT	Any valid sensor reading
55	85	Channel 27 Reading	R	2	FLOAT	Any valid sensor reading
57	87	Channel 28 Reading	R	2	FLOAT	Any valid sensor reading
59	89	Channel 29 Reading	R	2	FLOAT	Any valid sensor reading
5B	91	Channel 30 Reading	R	2	FLOAT	Any valid sensor reading
5D	93	Channel 31 Reading	R	2	FLOAT	Any valid sensor reading
5F	95	Channel 32 Reading	R	2	FLOAT	Any valid sensor reading
61	97	Channel 1 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
62	98	Channel 2 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
63	99	Channel 3 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
64	100	Channel 4 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below

65	101	Channel 5 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
66	102	Channel 6 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
67	103	Channel 7 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
68	104	Channel 8 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
69	105	Channel 9 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
6A	106	Channel 10 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
6B	107	Channel 11 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
6C	108	Channel 12 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
6D	109	Channel 13 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
6E	110	Channel 14 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
6F	111	Channel 15 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
70	112	Channel 16 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
71	113	Channel 17 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
72	114	Channel 18 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
73	115	Channel 19 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
74	116	Channel 20 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
75	117	Channel 21 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
76	118	Channel 22 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
77	119	Channel 23 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
78	120	Channel 24 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
79	121	Channel 25 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
7A	122	Channel 26 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
7B	123	Channel 27 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
7C	124	Channel 28 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
7D	125	Channel 29 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
7E	126	Channel 30 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
7F	127	Channel 31 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
80	128	Channel 32 Mode	R	1	ENUMERATION	0-7 See Mode Enumeration Below
81	129	Channel 1 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
83	131	Channel 2 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
85	133	Channel 3 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
87	135	Channel 4 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
89	137	Channel 5 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
8B	139	Channel 6 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
8D	141	Channel 7 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
8F	143	Channel 8 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
91	145	Channel 9 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
93	147	Channel 10 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
95	149	Channel 11 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)

Sheet1

97	151	Channel 12 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
99	153	Channel 13 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
9B	155	Channel 14 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
9D	157	Channel 15 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
9F	159	Channel 16 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
A1	161	Channel 17 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
A3	163	Channel 18 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
A5	165	Channel 19 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
A7	167	Channel 20 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
A9	169	Channel 21 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
AB	171	Channel 22 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
AD	173	Channel 23 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
AF	175	Channel 24 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
B1	177	Channel 25 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
B3	179	Channel 26 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
B5	181	Channel 27 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
B7	183	Channel 28 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
B9	185	Channel 29 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
BB	187	Channel 30 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
BD	189	Channel 31 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
BF	191	Channel 32 Battery	R	2	FLOAT	Sensor Input Voltage(>= 0.0)
C1	193	Channel 1 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
C2	194	Channel 2 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
C3	195	Channel 3 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
C4	196	Channel 4 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
C5	197	Channel 5 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
C6	198	Channel 6 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
C7	199	Channel 7 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
C8	200	Channel 8 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
C9	201	Channel 9 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
CA	202	Channel 10 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
CB	203	Channel 11 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
CC	204	Channel 12 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
CD	205	Channel 13 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
CE	206	Channel 14 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
CF	207	Channel 15 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
D0	208	Channel 16 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
D1	209	Channel 17 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
D2	210	Channel 18 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds

D3	211	Channel 19 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
D4	212	Channel 20 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
D5	213	Channel 21 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
D6	214	Channel 22 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
D7	215	Channel 23 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
D8	216	Channel 24 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
D9	217	Channel 25 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
DA	218	Channel 26 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
DB	219	Channel 27 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
DC	220	Channel 28 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
DD	221	Channel 29 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
DE	222	Channel 30 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
DF	223	Channel 31 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
E0	224	Channel 32 Sec Since Last Message	R	1	INTEGER	0-32768 Seconds
E1	225	Channel 1 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
E2	226	Channel 2 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
E3	227	Channel 3 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
E4	228	Channel 4 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
E5	229	Channel 5 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
E6	230	Channel 6 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
E7	231	Channel 7 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
E8	232	Channel 8 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
E9	233	Channel 9 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
EA	234	Channel 10 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
EB	235	Channel 11 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
EC	236	Channel 12 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
ED	237	Channel 13 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
EE	238	Channel 14 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
EF	239	Channel 15 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
F0	240	Channel 16 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
F1	241	Channel 17 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
F2	242	Channel 18 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
F3	243	Channel 19 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
F4	244	Channel 20 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
F5	245	Channel 21 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
F6	246	Channel 22 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
F7	247	Channel 23 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
F8	248	Channel 24 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
F9	249	Channel 25 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below

Sheet1

FA	250	Channel 26 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
FB	251	Channel 27 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
FC	252	Channel 28 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
FD	253	Channel 29 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
FE	254	Channel 30 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
FF	255	Channel 31 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
100	256	Channel 32 Sensor Type	R	1	ENUMERATION	0-31 See Sensor Type Enumeration Below
101	257	Channel 1 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
102	258	Channel 2 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
103	259	Channel 3 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
104	260	Channel 4 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
105	261	Channel 5 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
106	262	Channel 6 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
107	263	Channel 7 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
108	264	Channel 8 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
109	265	Channel 9 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
10A	266	Channel 10 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
10B	267	Channel 11 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
10C	268	Channel 12 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
10D	269	Channel 13 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
10E	270	Channel 14 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
10F	271	Channel 15 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
110	272	Channel 16 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
111	273	Channel 17 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
112	274	Channel 18 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
113	275	Channel 19 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
114	276	Channel 20 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
115	277	Channel 21 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
116	278	Channel 22 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
117	279	Channel 23 Gas type	R	1	ENUMERATION	0-127 See Gas Enumeration below
118	280	Channel 24 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
119	281	Channel 25 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
11A	282	Channel 26 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
11B	283	Channel 27 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
11C	284	Channel 28 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
11D	285	Channel 29 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
11E	286	Channel 30 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
11F	287	Channel 31 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below
120	288	Channel 32 Gas Type	R	1	ENUMERATION	0-127 See Gas Enumeration below

Sheet1

121	289	Channel 1 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
122	290	Channel 2 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
123	291	Channel 3 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
124	292	Channel 4 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
125	293	Channel 5 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
126	294	Channel 6 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
127	295	Channel 7 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
128	296	Channel 8 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
129	297	Channel 9 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
12A	298	Channel 10 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
12B	299	Channel 11 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
12C	300	Channel 12 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
12D	301	Channel 13 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
12E	302	Channel 14 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
12F	303	Channel 15 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
130	304	Channel 16 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
131	305	Channel 17 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
132	306	Channel 18 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
133	307	Channel 19 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
134	308	Channel 20 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
135	309	Channel 21 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
136	310	Channel 22 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
137	311	Channel 23 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
138	312	Channel 24 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
139	313	Channel 25 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
13A	314	Channel 26 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
13B	315	Channel 27 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
13C	316	Channel 28 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
13D	317	Channel 29 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
13E	318	Channel 30 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
13F	319	Channel 31 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
140	320	Channel 32 Fault	R	1	ENUMERATION	0-15 See Fault Enumeration below
141	321	Channel 1 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
142	322	Channel 2 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
143	323	Channel 3 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
144	324	Channel 4 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
145	325	Channel 5 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
146	326	Channel 6 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
147	327	Channel 7 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on

148	328	Channel 8 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
149	329	Channel 9 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
14A	330	Channel 10 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
14B	331	Channel 11 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
14C	332	Channel 12 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
14D	333	Channel 13 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
14E	334	Channel 14 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
14F	335	Channel 15 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
150	336	Channel 16 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
151	337	Channel 17 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
152	338	Channel 18 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
153	339	Channel 19 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
154	340	Channel 20 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
155	341	Channel 21 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
156	342	Channel 22 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
157	343	Channel 23 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
158	344	Channel 24 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
159	345	Channel 25 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
15A	346	Channel 26 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
15B	347	Channel 27 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
15C	348	Channel 28 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
15D	349	Channel 29 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
15E	350	Channel 30 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
15F	351	Channel 31 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
160	352	Channel 32 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
161	353	Channel 1 Relay 1 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
162	354	Channel 2 Relay 1 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
163	355	Channel 3 Relay 1 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
164	356	Channel 4 Relay 1 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
165	357	Channel 5 Relay 1 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
166	358	Channel 6 Relay 1 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
167	359	Channel 7 Relay 1 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
168	360	Channel 8 Relay 1 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
169	361	Channel 9 Relay 1 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
16A	362	Channel 10 Relay 1 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
16B	363	Channel 11 Relay 1 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
16C	364	Channel 12 Relay 1 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
16D	365	Channel 13 Relay 1 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on
16E	366	Channel 14 Relay 1 On/Off	R/W	1	ENUMERATION	0 – 1, 0 means off, 1 means on

Sheet1

16F	367	Channel 15 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
170	368	Channel 16 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
171	369	Channel 17 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
172	370	Channel 18 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
173	371	Channel 19 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
174	372	Channel 20 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
175	373	Channel 21 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
176	374	Channel 22 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
177	375	Channel 23 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
178	376	Channel 24 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
179	377	Channel 25 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
17A	378	Channel 26 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
17B	379	Channel 27 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
17C	380	Channel 28 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
17D	381	Channel 29 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
17E	382	Channel 30 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
17F	383	Channel 31 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
180	384	Channel 32 Relay 1 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
181	385	Channel 1 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
182	386	Channel 2 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
183	387	Channel 3 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
184	388	Channel 4 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
185	389	Channel 5 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
186	390	Channel 6 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
187	391	Channel 7 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
188	392	Channel 8 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
189	393	Channel 9 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
18A	394	Channel 10 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
18B	395	Channel 11 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
18C	396	Channel 12 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
18D	397	Channel 13 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
18E	398	Channel 14 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
18F	399	Channel 15 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
190	400	Channel 16 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
191	401	Channel 17 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
192	402	Channel 18 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
193	403	Channel 19 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
194	404	Channel 20 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
195	405	Channel 21 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high

196	406	Channel 22 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
197	407	Channel 23 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
198	408	Channel 24 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
199	409	Channel 25 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
19A	410	Channel 26 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
19B	411	Channel 27 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
19C	412	Channel 28 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
19D	413	Channel 29 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
19E	414	Channel 30 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
19F	415	Channel 31 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
1A0	416	Channel 32 Relay 1 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
1A1	417	Channel 1 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1A3	419	Channel 2 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1A5	421	Channel 3 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1A7	423	Channel 4 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1A9	425	Channel 5 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1AB	427	Channel 6 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1AD	429	Channel 7 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1AF	431	Channel 8 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1B1	433	Channel 9 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1B3	435	Channel 10 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1B5	437	Channel 11 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1B7	439	Channel 12 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1B9	441	Channel 13 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1BB	443	Channel 14 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1BD	445	Channel 15 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1BF	447	Channel 16 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1C1	449	Channel 17 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1C3	451	Channel 18 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1C5	453	Channel 19 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1C7	455	Channel 20 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1C9	457	Channel 21 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1CB	459	Channel 22 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1CD	461	Channel 23 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1CF	463	Channel 24 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1D1	465	Channel 25 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1D3	467	Channel 26 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1D5	469	Channel 27 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1D7	471	Channel 28 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0

Sheet1

1D9	473	Channel 29 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1DB	475	Channel 30 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1DD	477	Channel 31 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1DF	479	Channel 32 Relay 1 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
1E1	481	Channel 1 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1E2	482	Channel 2 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1E3	483	Channel 3 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1E4	484	Channel 4 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1E5	485	Channel 5 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1E6	486	Channel 6 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1E7	487	Channel 7 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1E8	488	Channel 8 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1E9	489	Channel 9 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1EA	490	Channel 10 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1EB	491	Channel 11 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1EC	492	Channel 12 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1ED	493	Channel 13 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1EE	494	Channel 14 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1EF	495	Channel 15 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1F0	496	Channel 16 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1F1	497	Channel 17 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1F2	498	Channel 18 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1F3	499	Channel 19 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1F4	500	Channel 20 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1F5	501	Channel 21 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1F6	502	Channel 22 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1F7	503	Channel 23 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1F8	504	Channel 24 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1F9	505	Channel 25 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1FA	506	Channel 26 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1FB	507	Channel 27 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1FC	508	Channel 28 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1FD	509	Channel 29 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1FE	510	Channel 30 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
1FF	511	Channel 31 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
200	512	Channel 32 Relay 1 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
201	513	Channel 1 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1 ,0 means off, 1 means on
202	514	Channel 2 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1 ,0 means off, 1 means on
203	515	Channel 3 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1 ,0 means off, 1 means on

204	516	Channel 4 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
205	517	Channel 5 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
206	518	Channel 6 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
207	519	Channel 7 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
208	520	Channel 8 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
209	521	Channel 9 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
20A	522	Channel 10 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
20B	523	Channel 11 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
20C	524	Channel 12 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
20D	525	Channel 13 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
20E	526	Channel 14 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
20F	527	Channel 15 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
210	528	Channel 16 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
211	529	Channel 17 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
212	530	Channel 18 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
213	531	Channel 19 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
214	532	Channel 20 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
215	533	Channel 21 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
216	534	Channel 22 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
217	535	Channel 23 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
218	536	Channel 24 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
219	537	Channel 25 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
21A	538	Channel 26 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
21B	539	Channel 27 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
21C	540	Channel 28 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
21D	541	Channel 29 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
21E	542	Channel 30 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
21F	543	Channel 31 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
220	544	Channel 32 Relay 2 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
221	545	Channel 1 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
222	546	Channel 2 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
223	547	Channel 3 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
224	548	Channel 4 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
225	549	Channel 5 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
226	550	Channel 6 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
227	551	Channel 7 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
228	552	Channel 8 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
229	553	Channel 9 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
22A	554	Channel 10 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high

22B	555	Channel 11 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
22C	556	Channel 12 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
22D	557	Channel 13 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
22E	558	Channel 14 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
22F	559	Channel 15 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
230	560	Channel 16 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
231	561	Channel 17 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
232	562	Channel 18 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
233	563	Channel 19 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
234	564	Channel 20 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
235	565	Channel 21 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
236	566	Channel 22 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
237	567	Channel 23 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
238	568	Channel 24 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
239	569	Channel 25 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
23A	570	Channel 26 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
23B	571	Channel 27 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
23C	572	Channel 28 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
23D	573	Channel 29 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
23E	574	Channel 30 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
23F	575	Channel 31 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
240	576	Channel 32 Relay 2 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
241	577	Channel 1 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
243	579	Channel 2 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
245	581	Channel 3 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
247	583	Channel 4 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
249	585	Channel 5 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
24B	587	Channel 6 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
24D	589	Channel 7 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
24F	591	Channel 8 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
251	593	Channel 9 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
253	595	Channel 10 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
255	597	Channel 11 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
257	599	Channel 12 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
259	601	Channel 13 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
25B	603	Channel 14 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
25D	605	Channel 15 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
25F	607	Channel 16 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
261	609	Channel 17 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0

Sheet1

263	611	Channel 18 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
265	613	Channel 19 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
267	615	Channel 20 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
269	617	Channel 21 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
26B	619	Channel 22 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
26D	621	Channel 23 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
26F	623	Channel 24 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
271	625	Channel 25 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
273	627	Channel 26 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
275	629	Channel 27 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
277	631	Channel 28 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
279	633	Channel 29 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
27B	635	Channel 30 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
27D	637	Channel 31 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
27F	639	Channel 32 Relay 2 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
281	641	Channel 1 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
282	642	Channel 2 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
283	643	Channel 3 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
284	644	Channel 4 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
285	645	Channel 5 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
286	646	Channel 6 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
287	647	Channel 7 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
288	648	Channel 8 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
289	649	Channel 9 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
28A	650	Channel 10 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
28B	651	Channel 11 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
28C	652	Channel 12 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
28D	653	Channel 13 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
28E	654	Channel 14 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
28F	655	Channel 15 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
290	656	Channel 16 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
291	657	Channel 17 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
292	658	Channel 18 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
293	659	Channel 19 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
294	660	Channel 20 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
295	661	Channel 21 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
296	662	Channel 22 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
297	663	Channel 23 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
298	664	Channel 24 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch

Sheet1

299	665	Channel 25 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
29A	666	Channel 26 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
29B	667	Channel 27 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
29C	668	Channel 28 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
29D	669	Channel 29 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
29E	670	Channel 30 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
29F	671	Channel 31 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
2A0	672	Channel 32 Relay 2 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
2A1	673	Channel 1 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on
2A2	674	Channel 2 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on
2A3	675	Channel 3 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on
2A4	676	Channel 4 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on
2A5	677	Channel 5 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on
2A6	678	Channel 6 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on
2A7	679	Channel 7 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on
2A8	680	Channel 8 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on
2A9	681	Channel 9 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on
2AA	682	Channel 10 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on
2AB	683	Channel 11 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on
2AC	684	Channel 12 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on
2AD	685	Channel 13 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on
2AE	686	Channel 14 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on
2AF	687	Channel 15 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on
2B0	688	Channel 16 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on
2B1	689	Channel 17 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on
2B2	690	Channel 18 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on
2B3	691	Channel 19 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on
2B4	692	Channel 20 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on
2B5	693	Channel 21 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on
2B6	694	Channel 22 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on
2B7	695	Channel 23 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on
2B8	696	Channel 24 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on
2B9	697	Channel 25 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on
2BA	698	Channel 26 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on
2BB	699	Channel 27 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on
2BC	700	Channel 28 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on
2BD	701	Channel 29 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on
2BE	702	Channel 30 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on
2BF	703	Channel 31 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1 , 0 means off, 1 means on

Sheet1

2C0	704	Channel 32 Relay 3 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
2C1	705	Channel 1 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2C2	706	Channel 2 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2C3	707	Channel 3 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2C4	708	Channel 4 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2C5	709	Channel 5 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2C6	710	Channel 6 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2C7	711	Channel 7 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2C8	712	Channel 8 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2C9	713	Channel 9 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2CA	714	Channel 10 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2CB	715	Channel 11 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2CC	716	Channel 12 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2CD	717	Channel 13 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2CE	718	Channel 14 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2CF	719	Channel 15 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2D0	720	Channel 16 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2D1	721	Channel 17 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2D2	722	Channel 18 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2D3	723	Channel 19 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2D4	724	Channel 20 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2D5	725	Channel 21 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2D6	726	Channel 22 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2D7	727	Channel 23 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2D8	728	Channel 24 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2D9	729	Channel 25 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2DA	730	Channel 26 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2DB	731	Channel 27 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2DC	732	Channel 28 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2DD	733	Channel 29 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2DE	734	Channel 30 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2DF	735	Channel 31 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2E0	736	Channel 32 Relay 3 High/Low	R/W	1	ENUMERATION	0 - 1, 0 means low, 1 means high
2E1	737	Channel 1 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
2E3	739	Channel 2 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
2E5	741	Channel 3 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
2E7	743	Channel 4 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
2E9	745	Channel 5 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
2EB	747	Channel 6 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0

Sheet1

2ED	749	Channel 7 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
2EF	751	Channel 8 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
2F1	753	Channel 9 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
2F3	755	Channel 10 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
2F5	757	Channel 11 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
2F7	759	Channel 12 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
2F9	761	Channel 13 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
2FB	763	Channel 14 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
2FD	765	Channel 15 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
2FF	767	Channel 16 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
301	769	Channel 17 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
303	771	Channel 18 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
305	773	Channel 19 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
307	775	Channel 20 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
309	777	Channel 21 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
30B	779	Channel 22 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
30D	781	Channel 23 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
30F	783	Channel 24 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
311	785	Channel 25 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
313	787	Channel 26 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
315	789	Channel 27 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
317	791	Channel 28 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
319	793	Channel 29 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
31B	795	Channel 30 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
31D	797	Channel 31 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
31F	799	Channel 32 Relay 3 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
321	801	Channel 1 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
322	802	Channel 2 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
323	803	Channel 3 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
324	804	Channel 4 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
325	805	Channel 5 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
326	806	Channel 6 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
327	807	Channel 7 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
328	808	Channel 8 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
329	809	Channel 9 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
32A	810	Channel 10 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
32B	811	Channel 11 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
32C	812	Channel 12 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
32D	813	Channel 13 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch

Sheet1

32E	814	Channel 14 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
32F	815	Channel 15 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
330	816	Channel 16 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
331	817	Channel 17 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
332	818	Channel 18 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
333	819	Channel 19 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
334	820	Channel 20 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
335	821	Channel 21 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
336	822	Channel 22 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
337	823	Channel 23 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
338	824	Channel 24 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
339	825	Channel 25 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
33A	826	Channel 26 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
33B	827	Channel 27 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
33C	828	Channel 28 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
33D	829	Channel 29 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
33E	830	Channel 30 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
33F	831	Channel 31 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
340	832	Channel 32 Relay 3 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
341	833	Channel 1 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1 ,0 means off, 1 means on
342	834	Channel 2 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1 ,0 means off, 1 means on
343	835	Channel 3 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1 ,0 means off, 1 means on
344	836	Channel 4 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1 ,0 means off, 1 means on
345	837	Channel 5 Relay 4 On/4ff	R/W	1	ENUMERATION	0 - 1 ,0 means off, 1 means on
346	838	Channel 6 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1 ,0 means off, 1 means on
347	839	Channel 7 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1 ,0 means off, 1 means on
348	840	Channel 8 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1 ,0 means off, 1 means on
349	841	Channel 9 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1 ,0 means off, 1 means on
34A	842	Channel 10 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1 ,0 means off, 1 means on
34B	843	Channel 11 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1 ,0 means off, 1 means on
34C	844	Channel 12 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1 ,0 means off, 1 means on
34D	845	Channel 13 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1 ,0 means off, 1 means on
34E	846	Channel 14 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1 ,0 means off, 1 means on
34F	847	Channel 15 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1 ,0 means off, 1 means on
350	848	Channel 16 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1 ,0 means off, 1 means on
351	849	Channel 17 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1 ,0 means off, 1 means on
352	850	Channel 18 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1 ,0 means off, 1 means on
353	851	Channel 19 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1 ,0 means off, 1 means on
354	852	Channel 20 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1 ,0 means off, 1 means on

355	853	Channel 21 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
356	854	Channel 22 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
357	855	Channel 23 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
358	856	Channel 24 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
359	857	Channel 25 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
35A	858	Channel 26 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
35B	859	Channel 27 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
35C	860	Channel 28 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
35D	861	Channel 29 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
35E	862	Channel 30 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
35F	863	Channel 31 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
360	864	Channel 32 Relay 4 On/Off	R/W	1	ENUMERATION	0 - 1, 0 means off, 1 means on
361	865	Channel 1 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
362	866	Channel 2 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
363	867	Channel 3 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
364	868	Channel 4 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
365	869	Channel 5 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
366	870	Channel 6 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
367	871	Channel 7 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
368	872	Channel 8 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
369	873	Channel 9 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
36A	874	Channel 10 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
36B	875	Channel 11 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
36C	876	Channel 12 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
36D	877	Channel 13 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
36E	878	Channel 14 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
36F	879	Channel 15 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
370	880	Channel 16 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
371	881	Channel 17 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
372	882	Channel 18 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
373	883	Channel 19 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
374	884	Channel 20 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
375	885	Channel 21 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
376	886	Channel 22 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
377	887	Channel 23 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
378	888	Channel 24 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
379	889	Channel 25 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
37A	890	Channel 26 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
37B	891	Channel 27 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high

Sheet1

37C	892	Channel 28 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
37D	893	Channel 29 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
37E	894	Channel 30 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
37F	895	Channel 31 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
380	896	Channel 32 Relay 4 High/Low	R/W	1	ENUMERATION	0 - 1 ,0 means low, 1 means high
381	897	Channel 1 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
383	899	Channel 2 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
385	901	Channel 3 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
387	903	Channel 4 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
389	905	Channel 5 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
38B	907	Channel 6 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
38D	909	Channel 7 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
38F	911	Channel 8 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
391	913	Channel 9 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
393	915	Channel 10 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
395	917	Channel 11 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
397	919	Channel 12 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
399	921	Channel 13 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
39B	923	Channel 14 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
39D	925	Channel 15 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
39F	927	Channel 16 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3A1	929	Channel 17 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3A3	931	Channel 18 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3A5	933	Channel 19 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3A7	935	Channel 20 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3A9	937	Channel 21 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3AB	939	Channel 22 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3AD	941	Channel 23 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3AF	943	Channel 24 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3B1	945	Channel 25 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3B3	947	Channel 26 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3B5	949	Channel 27 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3B7	951	Channel 28 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3B9	953	Channel 29 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3BB	955	Channel 30 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3BD	957	Channel 31 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3BF	959	Channel 32 Relay 4 Set Point	R/W	2	FLOAT	Any number 65000 or less and higher than 0
3C1	961	Channel 1 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3C2	962	Channel 2 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch

3C3	963	Channel 3 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3C4	964	Channel 4 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3C5	965	Channel 5 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3C6	966	Channel 6 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3C7	967	Channel 7 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3C8	968	Channel 8 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3C9	969	Channel 9 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3CA	970	Channel 10 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3CB	971	Channel 11 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3CC	972	Channel 12 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3CD	973	Channel 13 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3CE	974	Channel 14 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3CF	975	Channel 15 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3D0	976	Channel 16 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3D1	977	Channel 17 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3D2	978	Channel 18 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3D3	979	Channel 19 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3D4	980	Channel 20 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3D5	981	Channel 21 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3D6	982	Channel 22 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3D7	983	Channel 23 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3D8	984	Channel 24 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3D9	985	Channel 25 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3DA	986	Channel 26 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3DB	987	Channel 27 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3DC	988	Channel 28 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3DD	989	Channel 29 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3DE	990	Channel 30 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3DF	991	Channel 31 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3E0	992	Channel 32 Relay 4 Latch/Unlatch	R/W	1	ENUMERATION	0 - 1 ,0 means unlatch, 1 means latch
3E1	993	Channel 1 Time Since Last Nulled	R	1	ENUMERATION	0-65000
3E2	994	Channel 2 Time Since Last Nulled	R	1	ENUMERATION	0-65000
3E3	995	Channel 3 Time Since Last Nulled	R	1	ENUMERATION	0-65000
3E4	996	Channel 4 Time Since Last Nulled	R	1	ENUMERATION	0-65000
3E5	997	Channel 5 Time Since Last Nulled	R	1	ENUMERATION	0-65000
3E6	998	Channel 6 Time Since Last Nulled	R	1	ENUMERATION	0-65000
3E7	999	Channel 7 Time Since Last Nulled	R	1	ENUMERATION	0-65000
3E8	1000	Channel 8 Time Since Last Nulled	R	1	ENUMERATION	0-65000
3E9	1001	Channel 9 Time Since Last Nulled	R	1	ENUMERATION	0-65000

3EA	1002	Channel 10 Time Since Last Nulled	R	1	ENUMERATION	0-65000
3EB	1003	Channel 11 Time Since Last Nulled	R	1	ENUMERATION	0-65000
3EC	1004	Channel 12 Time Since Last Nulled	R	1	ENUMERATION	0-65000
3ED	1005	Channel 13 Time Since Last Nulled	R	1	ENUMERATION	0-65000
3EE	1006	Channel 14 Time Since Last Nulled	R	1	ENUMERATION	0-65000
3EF	1007	Channel 15 Time Since Last Nulled	R	1	ENUMERATION	0-65000
3F0	1008	Channel 16 Time Since Last Nulled	R	1	ENUMERATION	0-65000
3F1	1009	Channel 17 Time Since Last Nulled	R	1	ENUMERATION	0-65000
3F2	1010	Channel 18 Time Since Last Nulled	R	1	ENUMERATION	0-65000
3F3	1011	Channel 19 Time Since Last Nulled	R	1	ENUMERATION	0-65000
3F4	1012	Channel 20 Time Since Last Nulled	R	1	ENUMERATION	0-65000
3F5	1013	Channel 21 Time Since Last Nulled	R	1	ENUMERATION	0-65000
3F6	1014	Channel 22 Time Since Last Nulled	R	1	ENUMERATION	0-65000
3F7	1015	Channel 23 Time Since Last Nulled	R	1	ENUMERATION	0-65000
3F8	1016	Channel 24 Time Since Last Nulled	R	1	ENUMERATION	0-65000
3F9	1017	Channel 25 Time Since Last Nulled	R	1	ENUMERATION	0-65000
3FA	1018	Channel 26 Time Since Last Nulled	R	1	ENUMERATION	0-65000
3FB	1019	Channel 27 Time Since Last Nulled	R	1	ENUMERATION	0-65000
3FC	1020	Channel 28 Time Since Last Nulled	R	1	ENUMERATION	0-65000
3FD	1021	Channel 29 Time Since Last Nulled	R	1	ENUMERATION	0-65000
3FE	1022	Channel 30 Time Since Last Nulled	R	1	ENUMERATION	0-65000
3FF	1023	Channel 31 Time Since Last Nulled	R	1	ENUMERATION	0-65000
400	1024	Channel 32 Time Since Last Nulled	R	1	ENUMERATION	0-65000
401	1025	Channel 1 Time Since Last Cal	R	1	ENUMERATION	0-65000
402	1026	Channel 2 Time Since Last Cal	R	1	ENUMERATION	0-65000
403	1027	Channel 3 Time Since Last Cal	R	1	ENUMERATION	0-65000
404	1028	Channel 4 Time Since Last Cal	R	1	ENUMERATION	0-65000
405	1029	Channel 5 Time Since Last Cal	R	1	ENUMERATION	0-65000
406	1030	Channel 6 Time Since Last Cal	R	1	ENUMERATION	0-65000
407	1031	Channel 7 Time Since Last Cal	R	1	ENUMERATION	0-65000
408	1032	Channel 8 Time Since Last Cal	R	1	ENUMERATION	0-65000
409	1033	Channel 9 Time Since Last Cal	R	1	ENUMERATION	0-65000
40A	1034	Channel 10 Time Since Last Cal	R	1	ENUMERATION	0-65000
40B	1035	Channel 11 Time Since Last Cal	R	1	ENUMERATION	0-65000
40C	1036	Channel 12 Time Since Last Cal	R	1	ENUMERATION	0-65000
40D	1037	Channel 13 Time Since Last Cal	R	1	ENUMERATION	0-65000
40E	1038	Channel 14 Time Since Last Cal	R	1	ENUMERATION	0-65000
40F	1039	Channel 15 Time Since Last Cal	R	1	ENUMERATION	0-65000
410	1040	Channel 16 Time Since Last Cal	R	1	ENUMERATION	0-65000

411	1041	Channel 17 Time Since Last Cal	R	1	ENUMERATION	0-65000
412	1042	Channel 18 Time Since Last Cal	R	1	ENUMERATION	0-65000
413	1043	Channel 19 Time Since Last Cal	R	1	ENUMERATION	0-65000
414	1044	Channel 20 Time Since Last Cal	R	1	ENUMERATION	0-65000
415	1045	Channel 21 Time Since Last Cal	R	1	ENUMERATION	0-65000
416	1046	Channel 22 Time Since Last Cal	R	1	ENUMERATION	0-65000
417	1047	Channel 23 Time Since Last Cal	R	1	ENUMERATION	0-65000
418	1048	Channel 24 Time Since Last Cal	R	1	ENUMERATION	0-65000
419	1049	Channel 25 Time Since Last Cal	R	1	ENUMERATION	0-65000
41A	1050	Channel 26 Time Since Last Cal	R	1	ENUMERATION	0-65000
41B	1051	Channel 27 Time Since Last Cal	R	1	ENUMERATION	0-65000
41C	1052	Channel 28 Time Since Last Cal	R	1	ENUMERATION	0-65000
41D	1053	Channel 29 Time Since Last Cal	R	1	ENUMERATION	0-65000
41E	1054	Channel 30 Time Since Last Cal	R	1	ENUMERATION	0-65000
41F	1055	Channel 31 Time Since Last Cal	R	1	ENUMERATION	0-65000
420	1056	Channel 32 Time Since Last Cal	R	1	ENUMERATION	0-65000
421	1057	Channel 29 Select Wired or Radio	R/W	1	ENUMERATION	0 - 1 ,0 means wired, 1 means radio
422	1058	Channel 30 Select Wired or Radio	R/W	1	ENUMERATION	0 - 1 ,0 means wired, 1 means radio
423	1059	Channel 31 Select Wired or Radio	R/W	1	ENUMERATION	0 - 1 ,0 means wired, 1 means radio
424	1060	Channel 32 Select Wired or Radio	R/W	1	ENUMERATION	0 - 1 ,0 means wired, 1 means radio
425	1061	Channel 29 Scale	R/W	1	INTEGER	10—65000
426	1062	Channel 30 Scale	R/W	1	INTEGER	10—65000
427	1063	Channel 31 Scale	R/W	1	INTEGER	10—65000
428	1064	Channel 32 Scale	R/W	1	INTEGER	10—65000
Modbus and Build Data						
1771	6001	Modbus Address	R/W	1	INTEGER	1 - 247
1772	6002	Modbus Baud Rate	R/W	1	INTEGER	
1773	6003	Month	R	1	INTEGER	1 - 12
1774	6004	Day	R	1	INTEGER	1 - 31
1775	6005	Year	R	1	INTEGER	2009 -
1776	6006	Serial Number Character	R	1	ENUMERATION	0 - 26 See Serial Number below
1777	6007	Serial Number	R	2	LONG INT	1 - 99999
Settings in Startup Menu						
177A	6010	Can Change Startup Menu Options	R	1	ENUMERATION	0 - 1, 1 can change startup menu items. 0 cannot change.
177B	6011	Return to Factory Default	R/W	1	ENUMERATION	When read will be 0. When you want to restore write a 1.
177C	6012	Relay 4 as Fault Relay	R/W	1	ENUMERATION	0 - 1, 0 means normal relay, 1 means Fault Relay
177D	6013	Relay 1 Fail Safe	R/W	1	ENUMERATION	0 - 1, 0 means not Fail Safe, 1 means Fail Safe
177E	6014	Relay 2 Fail Safe	R/W	1	ENUMERATION	0 - 1, 0 means not Fail Safe, 1 means Fail Safe
177F	6015	Relay 3 Fail Safe	R/W	1	ENUMERATION	0 - 1, 0 means not Fail Safe, 1 means Fail Safe

1780	6016	Relay 4 Fail Safe	R/W	1	ENUMERATION	0 – 1, 0 means not Fail Safe, 1 means Fail Safe
1781	6017	Fault Terminal Fail Safe	R/W	1	ENUMERATION	0 – 1, 0 means not Fail Safe, 1 means Fail Safe
1782	6018	Radio Timeout	R/W	1	INTEGER	6-255. This is the timeout in minutes.
1783	6019	Network Channel	R/W	1	INTEGER	1—78
1784	6020	Primary Secondary	R/W	1	ENUMERATION	0 – 1, 0 is Primary and 1 is Secondary
Relays in Alarm State						
1785	6021	Relay 1 is in Alarm	R	1	ENUMERATION	0 – 1, 0 means not in Alarm, 1 means in Alarm
1786	6022	Relay 2 is in Alarm	R	1	ENUMERATION	0 – 1, 0 means not in Alarm, 1 means in Alarm
1787	6023	Relay 3 is in Alarm	R	1	ENUMERATION	0 – 1, 0 means not in Alarm, 1 means in Alarm
1788	6024	Relay 4 is in Alarm	R	1	ENUMERATION	0 – 1, 0 means not in Alarm, 1 means in Alarm
1789	6025	Fault Relay is in Alarm	R	1	ENUMERATION	0 – 1, 0 means not in Alarm, 1 means in Alarm
178A	6026	Channels 1-32 in Alarm	R	2	ENUMERATION	Each byte corresponds to a Channel. 1 means in Alarm
178C	6028	Channels 33-64 in Alarm	R	2	ENUMERATION	Each byte corresponds to a Channel. 1 means in Alarm
178E	6030	Reset Relays	R/W	1	ENUMERATION	Reads always a 0. Write 1 to reset the relays.
178F	6031	Channels in Fault	R	1	ENUMERATION	0 – 3, 0 no fault, 1 fault 1-16, 2 fault 17-32, 3 fault on both
1790	6032	Channels On	R	1	ENUMERATION	Bit Enumeration found on table below.
1791	6033	Fault: There is another Primary Monitor	R	1	ENUMERATION	0-1, 0 means no fault, 1 means there is another Primary
1792	6034	Put into Cal Mode	R/W	1	ENUMERATION	0-1, 0 means not in Cal Mode
1793	6035	Put into Test Mode	R/W	1	ENUMERATION	0-1, 0 means not in Test Mode
1794	6036	Relay 1 First 16 Channels Alarm Was On	R	1	ENUMERATION	Each byte corresponds to a Channel. 1 means was in Alarm
1795	6037	Relay 1 Second 16 Channels Alarm Was On	R	1	ENUMERATION	Each byte corresponds to a Channel. 1 means was in Alarm
1796	6038	Relay 2 First 16 Channels Alarm Was On	R	1	ENUMERATION	Each byte corresponds to a Channel. 1 means was in Alarm
1797	6039	Relay 2 Second 16 Channels Alarm Was On	R	1	ENUMERATION	Each byte corresponds to a Channel. 1 means was in Alarm
1798	6040	Relay 3 First 16 Channels Alarm Was On	R	1	ENUMERATION	Each byte corresponds to a Channel. 1 means was in Alarm
1799	6041	Relay 3 Second 16 Channels Alarm Was On	R	1	ENUMERATION	Each byte corresponds to a Channel. 1 means was in Alarm
179A	6042	Relay 4 First 16 Channels Alarm Was On	R	1	ENUMERATION	Each byte corresponds to a Channel. 1 means was in Alarm
179B	6043	Relay 4 Second 16 Channels Alarm Was On	R	1	ENUMERATION	Each byte corresponds to a Channel. 1 means was in Alarm
Miscellaneous						
179C	6044	Auto Scroll	R/W	1	ENUMERATION	0- 1, 1 is Autoscroll is on. 0 Autoscroll is off
179D	6045	Current Page	R	1	ENUMERATION	See Below
179E	6046	Needs to be blank for current page write.	R	1	ZERO	Always read as zero. Only here so current page works.
179F	6047	Duplicate Channel	R/W	1	INTEGER	Send channel you want duplicated, reads as 0
17A0	6048	Monitor Type	R	1	ENUMERATION	1-Primary, 2-Secondary, 3-New Primary
17A1	6049	Laird Radio Present	R	1	ENUMERATION	0-No Laird, 1- Laird
Location Names						
1B59	7001	Channel 1 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B5A	7002	Channel 1 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B5B	7003	Channel 1 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B5C	7004	Channel 1 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character

1B5D	7005	Channel 1 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B5E	7006	Channel 2 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B5F	7007	Channel 2 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B60	7008	Channel 2 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B61	7009	Channel 2 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B62	7010	Channel 2 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B63	7011	Channel 3 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B64	7012	Channel 3 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B65	7013	Channel 3 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B66	7014	Channel 3 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B67	7015	Channel 3 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B68	7016	Channel 4 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B69	7017	Channel 4 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B6A	7018	Channel 4 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B6B	7019	Channel 4 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B6C	7020	Channel 4 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B6D	7021	Channel 5 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B6E	7022	Channel 5 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B6F	7023	Channel 5 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B70	7024	Channel 5 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B71	7025	Channel 5 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B72	7026	Channel 6 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B73	7027	Channel 6 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B74	7028	Channel 6 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B75	7029	Channel 6 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B76	7030	Channel 6 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B77	7031	Channel 7 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B78	7032	Channel 7 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B79	7033	Channel 7 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B7A	7034	Channel 7 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B7B	7035	Channel 7 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B7C	7036	Channel 8 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B7D	7037	Channel 8 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B7E	7038	Channel 8 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B7F	7039	Channel 8 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B80	7040	Channel 8 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B81	7041	Channel 9 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B82	7042	Channel 9 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B83	7043	Channel 9 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character

1B84	7044	Channel 9 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B85	7045	Channel 9 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B86	7046	Channel 10 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B87	7047	Channel 10 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B88	7048	Channel 10 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B89	7049	Channel 10 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B8A	7050	Channel 10 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B8B	7051	Channel 11 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B8C	7052	Channel 11 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B8D	7053	Channel 11 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B8E	7054	Channel 11 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B8F	7055	Channel 11 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B90	7056	Channel 12 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B91	7057	Channel 12 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B92	7058	Channel 12 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B93	7059	Channel 12 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B94	7060	Channel 12 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B95	7061	Channel 13 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B96	7062	Channel 13 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B97	7063	Channel 13 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B98	7064	Channel 13 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B99	7065	Channel 13 Ninth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B9A	7066	Channel 14 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B9B	7067	Channel 14 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B9C	7068	Channel 14 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B9D	7069	Channel 14 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B9E	7070	Channel 14 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1B9F	7071	Channel 15 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BA0	7072	Channel 15 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BA1	7073	Channel 15 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BA2	7074	Channel 15 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BA3	7075	Channel 15 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BA4	7076	Channel 16 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BA5	7077	Channel 16 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BA6	7078	Channel 16 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BA7	7079	Channel 16 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BA8	7080	Channel 16 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BA9	7081	Channel 17 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BAA	7082	Channel 17 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character

1BAB	7083	Channel 17 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BAC	7084	Channel 17 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BAD	7085	Channel 17 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BAE	7086	Channel 18 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BAF	7087	Channel 18 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BB0	7088	Channel 18 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BB1	7089	Channel 18 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BB2	7090	Channel 18 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BB3	7091	Channel 19 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BB4	7092	Channel 19 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BB5	7093	Channel 19 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BB6	7094	Channel 19 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BB7	7095	Channel 19 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BB8	7096	Channel 20 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BB9	7097	Channel 20 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BBA	7098	Channel 20 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BBB	7099	Channel 20 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BBC	7100	Channel 20 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BBD	7101	Channel 21 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BBE	7102	Channel 21 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BBF	7103	Channel 21 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BC0	7104	Channel 21 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BC1	7105	Channel 21 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BC2	7106	Channel 22 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BC3	7107	Channel 22 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BC4	7108	Channel 22 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BC5	7109	Channel 22 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BC6	7110	Channel 22 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BC7	7111	Channel 23 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BC8	7112	Channel 23 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BC9	7113	Channel 23 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BCA	7114	Channel 23 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BCB	7115	Channel 23 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BCC	7116	Channel 24 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BCD	7117	Channel 24 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BCE	7118	Channel 24 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BCF	7119	Channel 24 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BD0	7120	Channel 24 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BD1	7121	Channel 25 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character

1BD2	7122	Channel 25 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BD3	7123	Channel 25 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BD4	7124	Channel 25 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BD5	7125	Channel 25 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BD6	7126	Channel 26 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BD7	7127	Channel 26 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BD8	7128	Channel 26 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BD9	7129	Channel 26 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BDA	7130	Channel 26 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BDB	7131	Channel 27 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BDC	7132	Channel 27 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BDD	7133	Channel 27 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BDE	7134	Channel 27 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BDF	7135	Channel 27 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BE0	7136	Channel 28 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BE1	7137	Channel 28 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BE2	7138	Channel 28 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BE3	7139	Channel 28 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BE4	7140	Channel 28 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BE5	7141	Channel 29 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BE6	7142	Channel 29 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BE7	7143	Channel 29 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BE8	7144	Channel 29 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BE9	7145	Channel 29 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BEA	7146	Channel 30 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BEB	7147	Channel 30 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BEC	7148	Channel 30 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BED	7149	Channel 30 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BEE	7150	Channel 30 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BEF	7151	Channel 31 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BF0	7152	Channel 31 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BF1	7153	Channel 31 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BF2	7154	Channel 31 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BF3	7155	Channel 31 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BF4	7156	Channel 32 First & Second Letters of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BF5	7157	Channel 32 Third and Forth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BF6	7158	Channel 32 Fifth & Sixth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BF7	7159	Channel 32 Seventh & Eighth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character
1BF8	7160	Channel 32 Ninth & Tenth Letter of Location	R/W	1	ASCII Character	Any Normal ASCII Character

Diagnostics Data						
2701	9985	Revision Major	R	1	INTEGER	Any Integer Value
2702	9986	Revision Minor	R	1	INTEGER	Any Integer Value
2703	9987	Build Number	R	1	INTEGER	Any Integer Value
2704	9988	Reset	R/W	1	INTEGER	0, 1. If user sets to 1, 985 defaults to factory settings
2705	9989	Serial Receive Good Count	R	1	UINT	0 – 65535
2706	9990	Serial Receive Error Count	R	1	UINT	0 – 65535
2707	9991	Reserved	R	1	UINT	0
2708	9992	Reserved	R	1	UINT	0
2709	9993	Radio Receive Good Count	R	1	UINT	0 – 65535
270A	9994	Radio Receive Error Count	R	1	UINT	0 – 65535
270B	9995	Reserved	R	1	UINT	0
270C	9996	Reserved	R	1	UINT	0
270D	9997	Uptime Days	R	1	UINT	0 – 65535
270E	9998	Uptime Hours	R	1	UINT	0 – 65535
270F	9999	Uptime Minutes	R	1	UINT	0 – 65535

MODE SENSOR	MODE
0	NORMAL
1	NULL
2	CALIBRATION
3	RELAY
4	Radio ADD
5	Diagnostic/Batt
6	Advanced Menu
7	Admin Menu

GAS TYPE NUM	GAS
0	H2S
1	SO2
2	O2
3	CO
4	CL2
5	CO2
6	LEL
7	VOC
8	FEET
9	HCL
10	NH3
11	H2
12	CLO2

13	HCN
14	F2
15	HF
16	CH2O
17	NO2
18	O3
19	Inches
20	GAS_4_20
21..N	Future Gases

Sensor TYPE NUM	SENSOR
0	EC
1	IR
2	CB
3	MOS
4	PID
5..N	Future Sensors

FAULT	FAULT
0	NONE
1	Sensor Timeout
2	None
	High Battery
3	Current
	ADC not
4	responding
5	Future Error
6	Future Error
7	Checksum Error
	Two Sensors
8	Same Add
	Sensor Radio
9	Timeout
	When Sensor is
	wired, it means
	no sensor is
10	connected
11...12	Future Error
	Fault on Wired
13	Unit
14	Primary Down
15	Monitor Fault

Serial Number Char	Char
1	A
2	B

3	C
4	D
5	E
6	F
7	G
8	H
9	I
10	J
11	K
12	L
13	M
14	N
15	O
16	P
17	Q
18	R
19	S
20	T
21	U
22	V
23	W
24	X
25	Y
26	Z